Keeping Scientific Eyes on Fluids

KOFLOC contributes to SDGs by our cutting edge technologies of flow measurement and control for gas and liquid.



Fix our eyes on the new era of the mankind and the earth.

The surrounding environment of the Earth consists of gases and liquids

The technologies for measuring, controlling and generating them are essential to the development of the society and industry, being the bases for supporting part generation manufacturing.


With the motto, "Keeping Scientific Eyes on Fluids" KOFLOC has been seeking the measurement and control technologies for more than 70 years, centering around a micro flow rate of a fluid.

Accumulating the clients' trust in various fields, we now enjoy the top domestic share in many different fields today.

With new technologies to create the future for the humans and the Earth,

KOFLOC continues to make efforts to realize affluent living for people.





FLOW INSTRUMENTS GENERAL CATALOG 004

CONTENTS

Mass Flow Controller / Mass Flow Meter

Compared with mechanical flow meters and valves, mass flow controller/mass flow meter is less susceptible to the temperature and pressure because it is designed for mass flow rate measurement, and is capable of communicating a flow rate with an electric signal. It is used in every process and equipment which require accuracy, repeatability, responsiveness and cost effectiveness, such as semiconductors, optical fibers, analysis, fuel cells, FPD, biotechnology, food, environmental measurement, combustion gas control, factory equipment and experimental equipment. In addition to them, Karman vortex flow meters and ultrasonic flow meters are also lined up.

Variable Flow Meter

A variable flow meter contains a float in a conical tapered tube with its top end spread wider than the bottom end. The float moves up and down depending on the high/low flow rate, reading its balanced position to obtain the flow rate. We provide various products such as flow meters with valve capable of flow rate control as well as flow rate measurement, and flow meters with alarm function.

Flow Control Valve

Generally, a needle valve is used as a flow control valve, which adjusts the opening of a flow path, or a small orifice, with a bar-shaped needle to control a flow rate by resistance change of the flow path. We manufacture flow controllers combining a needle valve and a diaphragm, and proportional solenoid valves which control the flow rate electrically, in addition to various precision and simple needle valves.

Pressure Control Valve

The pressure control valves include reducing valves and back pressure valves. The reducing valve is a regulating valve designed to keep the constant secondary-side pressure against the fluctuating primary-side pressure. It is generally used in the first stage of the equipment. The back pressure valve is designed to release the pressure to keep the constant primary-side pressure when it exceeds a set value.

The Gas Generator / Engineering Device



FLOW INSTRUMENTS GENERAL CATALOG 006

How to use the catalog

Product warranty and period

Thank you for choosing our products. When placing an order for the product, the following conditions apply unless noted otherwise in the quotation, contract, or specifications.

Description of the warranty

Warranty period

The warranty period is one year after shipment within the scope of cur specifications.

Scope of warranty

In case our product has a defect due to reasons attributable to our responsibility during the warranty period, we will provide a replacement product or repair the defective product at our factory free of charge. Our scope of warranty does not include any damage caused by reasons not attributable to our responsibility, customer's loss of opportunity, loss of income, secondary disaster accident, damage on other than our product attributable to failure of our product, and other compensations.

Exclusions from the scope of warranty

The following cases are excluded from the scope of warranty even during the warranty period.

- a) Failure due to operational error, and unreasonable repair or modification.
- (Including cases when the actual conditions differ from manufacture specifications)
- b) Damage and failure due to a dropping of the product after purchase.
- c) Failure due to natural disasters such as fire, earthquake, flood and lightning, or a riot.
- d) Failure due to a mixture of foreign substances through the piping.
- e) Failure due to a peculiar problem attributable to a combination with incorporated equipment.
- f) Other cases determined not attributable to our responsibility.

Our scope of warranty excludes the customer's or customer's client's loss of opportunity and damage on other than our product, and other damage attributable to failure of our product.

Response to directives and regulations

For responses to various directives and regulations, specify a product name and inquire our sales office.

Pressure standards

All pressure standards used in our catalog are indicated in "gauge pressure (G)", not the "absolute pressure (abs)."

Upon using the product

Read the instruction manual thoroughly and use in compliance with the specifications.

Product improvement and specifications change

In order to further improve performance, note that the specifications, appearance and accessories are subject to change without prior notice.

Product price


- For the product price, inquire our sales office each time
- We make efforts to keep the product price unchanged as much as possible, but it may change without prior notice due to surging raw material prices, personnel expenses, and so on.
- Transportation expense, packaging expense, insurance cost and installation cost will be added separately.

Technical support

The technical documents on our products and FAQs are publicized and updated at our website.

Inquiry

If you have any question, opinion or request on our products, use an inquiry form available at our website or contact our sales office.



This catalog is accessible at our website as well.

https://www.kofloc.co.jp/en/





List of Mass Flow Controller / Mass Flow Meter
































List of Mass Flow Controller / Mass Flow Meter
















About Mass Flow Controller / Mass Flow Meter

Volume flow rate and mass flow rate


Roughly speaking, there are two types of gas flow meters; volume flow meters and mass flow meters. The volume flow meters include variable flow meters, positive displacement flow meters, differential pressure flow meters, etc., and the mass flow meters include Coriolis flow meters, vortex flow meters, thermal type flow meters, etc. KOFLOC's mechanical flow meters are classified into the variable flow meters among the volume flow meters, and the mass flow controllers (MFC) and mass flow meters (MFM) are classified into the thermal type flow meters among the mass flow meters.

The difference between the volume flow meter and the mass flow meter is explained by showing a simple example. As shown in Fig. 1, many volume flow meters are used in the state with each part opened to the atmosphere, that is, in the state free from internal pressure application. If the pressure is internally applied, the volume flow meter calibrated by opening to the atmosphere fails to indicate a correct flow rate, requiring a corrective calculation for a reading. Particularly



for soap-film flow meters, dry/wet gas meters, etc., the volume flow meter is opened to the atmosphere in use as a rule because even a slight resistance has a big effect. This is the same for KOFLOC's flow meters (variable flow meters). If the pressure fluctuates greatly or the gas temperature changes, causing the gas density to change, they fail to indicate accurate flow rate. Accordingly, it is necessary to predetermine constant pressure and temperature conditions or correct each factor for a reading.

On the other hand, the mass flow meter literally detects a flow rate in weight. Even if a fluid is compressed or a density changes, the same state can be defined. If a gas is detected in mass, an identical indication is obtained either in the previously mentioned flow or in the pressurized state as shown in Fig. 2. Accordingly, it can be actually installed anywhere in any flow sheet. It is very convenient and allows a system configuration with few errors in flow rate readings.




Principle of mass flow controller / mass flow meter

A flow rate sensor used for **KOFLOC's** mass flow controller / mass flow meter is generally called thermal flow sensor. The following describes its detection principle.

A resistance element with high temperature coefficient of resistance is wound around the upstream side (Rus) and downstream side (Rds) of a capillary, a sensor part (Fig. 3), respectively. Two resistance elements are heated by running a current to this. If no fluid flows inside the capillary at this time, both the upstream and downstream sides are balanced at the same temperature. (Solid line in the graph in Fig. 3, Zero flow rate = Zero-point position, generally so called for the mass flow controller / mass flow meter).

Fig. 3. Structure of sensor part



If the fluid starts flowing in this state, a temperature distribution changes as shown by a broken line in the graph in Fig. 3. At this time, the upstream side is deprived of the heat by the fluid and the heat deprived from the upstream side is given to the downstream side. That is, there occurs a temperature difference (ΔT) between the upstream and downstream sides.

Focusing on that this temperature difference (ΔT) has a functional relationship with the mass flow rate of the fluid, it functions as a thermal type mass flow meter capable of measuring a mass flow rate under certain conditions by taking out changes of each resistance value as electric signals, and amplifying and correcting them. This is the mass flow meter (**Fig. 4**).

Furthermore, the mass flow controller (Fig. 5) is capable of stable mass flow rate control hardly affected by changes of various conditions such as temperature and pressure, by controlling the opening of a flow rate control valve by a solenoid actuator through comparison control with an external flow rate setting signal based on a flow rate signal output from the sensor part.

Fig. 4. Structure of mass flow meter





Fig. 5. Structure of mass flow controller



Unit of flow rate

As described above, the mass flow controller / mass flow meter measures a mass flow rate regardless of the pressure and temperature. If the flow rate is expressed in mass, unfamiliar units are used, different from those generally used for fluid measurement such as g/min and kg/min. Accordingly, it is generally expressed in terms of the volume flow rate under the conditions for the reference pressure and temperature. Currently, the units such as Pa·m³/s are used in compliance with the SI unit system. Generally, however, the units, SCCM and SLM, which have been used for the mass flow controller / mass flow meter for decades are still the mainstream.

Concerning the definition of units, **KOFLOC** has been adopting the definition by the SEMI standard as the standard units for the mass flow controller / mass flow mater since October 1998.

SCCM, an initial word of Standard Cubic Centimeter per Minute, expresses a value converted into cc/mm at 0°C and under the atmospheric pressure, and SLM, an initial word of Standard Liter per Minute, expresses a value converted into L/min under the same conditions

In the non-semiconductor industries, the definition differs from one industry to another, such as SCCM and SLM at 20°C and under the atmospheric pressure, and NCCM and NLM at 0°C and under the atmospheric pressure. Accordingly, for the flow rate notation of our mass flow control / mass flow meter, specify the reference temperature and pressure, for example, SCCM (0°C, 1atm) or NLM (0°C, 1atm), when ordering our product.

Actual gas calibration and conversion factor method

As a rule, the thermal sensor can assure the accuracy only when it is calibrated with actual gas. Currently, we can calibrate with N_2 , Air, O_2 , H_2 , He, CO_2 and Ar as actual gases. For other gases, calibration is performed with N_2 or Air, using a constant conversion factor (C.F.) to N_2 .

For example, in case the N_2 -specification mass flow controller / mass flow meter is used to run Ar, if the C.F. of Ar is 1.4, it is actually run by 1.4 times more than an indication value of the mass flow controller / mass flow meter. That is, the flow rate of Ar is 1.4 × the

indication value of the N₂-specification mass flow controller / mass flow meter. The C.F. is available for different gases due to data accumulation by calculation or actual gas measurement, but there may be a deviation even for one gas or exist multiple conversion factors depending on the actual state of gas (temperature, pressure) and a combination of the sensor system of the mass flow controller / mass flow meter and the bypass (laminar flow element). Please consider the C.F. only as a guide.

About Mass Flow Controller / Mass Flow Meter

■ Wiring connection -- KFC standard

In order to save wiring, **KOFLOC** has been standardizing various electrical wiring connections since 1999. Currently, low-flow rate mass flow controllers / mass flow meters of 20 SLM or less (except for special and compact models) are unified to the KFC standard, D-sub 9 pins (**Fig. 6**). The unified products are indicated "KFC standard" in the specification column of this catalog.

For the products of other connector standards, wiring connections are described on the pages of individual mass flow controllers / mass flow meters. For details, see the instruction manual for the product.

Fig. 6. KFC Standard

Main unit connector --- D-sub 9 pins, male (M2.6 short screw)
Cable side connector --- D-sub 9 pins, female (M2.6 short screw)

Pin no.	Signal name
1	Valve open / close signal
2	Flow rate output signal
3	Power: +15V
4	Power COM
5	Power: -15V

^{*} For the mass flow meter, the pin nos. 1, 6, 8 and 9 are NC.

Pin no.	Signal name
6	Flow rate setting signal: Hi
7	Flow rate output signal COM
8	Flow rate setting signal: Lo
9	Valve voltage monitor

Notation of specifications

Notation of specifications for the mass flow controller / mass flow meter basically complies with the SEMI standard. The following describes typical definitions of specifications.

[1] Accuracy

Indicated in the form of $\pm XX\%$ F.S. (full scale). This value refers to a percent value to a full-scale value of an error with calibration gas(N₂, etc.) against our reference flow meter. Accordingly, in the case of a full scale range of 50 SCCM and the accuracy is $\pm 1\%$, the accuracy is assured against our reference flow rate with "uncertainty" of $50 \times (1/100) = \pm 0.5$ SCCM.

It may be also indicated in the form of $\pm XX\%$ S.P. (set point). This is a percent value to the set flow rate value.

[2] Repeatability

Refers to the degree of approximation of repeated set values at the values set from both upper and lower directions over a specified period and under specified operating conditions.

[3] Response

Starts control from zero flow rate and indicates a time to stabilize the mass flow controller's output at 98% of full scale. Normally indicated like this because 100% is tough to analyze in the case of asymptote.

Repair

In case your product has any trouble or failure due to secular change, and so on, we will repair it at our site as a rule. This is because the mass flow controller / mass flow meter itself is a precision device composed of very fine parts. When you notice any trouble or failure, check with the instruction manual, and then, contact our office.

^{*} The pin no. 9 differs depending on the model.

 $^{^{\}star}$ Note that the items in the specifications list, such as flow rate, response, accuracy and operating differential pressure, are specific to N₂ or Air.

About Karman Vortex Flow Meter / Ultrasonic Flow Meter

Principle of the Karman vortex flow meter

Theodore Von Karman, a hydrodynamicist, revealed theoretically in 1911 that when an object was placed in a flow of fluid, a regular vortex was alternately generated on the downstream side. This vortex row is called a Karman vortex (row) in honor of his name. The Karman vortex flow meter is based on the measurement principle of the Karman vortex.

As shown in Fig. 1, if a vortex generator is placed in a flow, the Karman vortex row is generated on the downstream side. At this time, suppose the vortex row's frequency is f, its flow velocity is v, and the width of the vortex generator is d, there is a relationship of

$$f = St \cdot \frac{V}{d}$$
(1)

The Karman vortex row is detected as a vortex frequency by a piezoelectric element disposed behind the vortex generator. Since this vortex frequency is proportional to the flow velocity in a certain range of Reynolds number, the flow velocity and flow rate can be measured by measuring the vortex frequency. The Strouhal number St is a dimensionless number decided by the shape and dimensions of the vortex generator. By selecting the shape and dimensions appropriately, it becomes a constant value over a wide range of Reynolds number.

Fig. 1. Karman vortex row





Fig. 2 shows the relations between the Reynolds number and the Strouhal number. If the Strouhal number is understood beforehand by Expression (1), the flow rate can be measured by measuring the vortex frequency. Some of KOFLOC's Karman vortex flow meters have a temperature sensor incorporated to correct the temperature (Reynolds correction) to the non-linear region of the Reynolds number and Strouhal number.

Fig. 2. Reynolds number vs. Strouhal number






Principle of the ultrasonic flow meter

Ultrasonic waves are elastic vibration waves (sound waves) with high frequency unhearable to humans. They are generally defined as 20kHz or higher acoustic vibrations.


Since the ultrasonic waves are acoustic vibrations, a medium such as a gas or a liquid is required to convey them. The ultrasonic waves are suitable for the flow meters which do not require the signals to reach far away like communication devices, because their propagation velocity is slower and their wavelength is shorter than electric waves (electromagnetic waves) using similar media.

There are several measurement methods for ultrasonic flow meters such as ultrasonic propagation time difference method, ultrasonic reciprocal propagation time method (frequency difference method) and Doppler method. Our method, "ultrasonic propagation time difference method," has ultrasonic transmitters / receivers attached to the piping on the upstream and downstream sides as shown in Fig. 3, alternately transmitting and receiving ultrasonic waves from the transmitter / receiver 1 to transmitter / receiver 2 and vice versa. The flow velocity is calculated from the difference in the alternately received ultrasonic propagation time, and the flow rate can be obtained by multiplying the cross-sectional area of the flow path by a correction factor.

Fig. 3. Principle of ultrasonic propagation time difference method







MODEL

FML-306-D

Connection tube size

1(1/2) inch

OD

38.1

017

MODEL

FML-306-N

Connection tube size

1(1/2) inch

OD

ID

НО


Dimensions (mm)

НО


ID

FML-300: Comparison of accuracy change between with and without temperature correction





Product used: FML-303, deviation from 25°C data (%F.S.)




Accuracy change by the fluid temperature at 16L/min. (without temperature correction)

Accuracy change by the fluid temperature at 16L/min. (with temperature correction)

Standard Specifications

MODEL			FML-301	FML-302	FML-303	FML-304	FML-305	FML-306
Connec	tion		3/8" tu	be end	1/2" tube end	3/4" tube end	1" tube end	1 (1/2)" tube end
Flow ra	nge		0.3 to 2.5L/min	0.4 to 4.0L/min	2.0 to 16L/min	5.0 to 50L/min	10 to 100L/min	25 to 250L/min
Fluid					Water, pure water	chemical solution		
Accurac	у			±2%F.5	S. (25°C)		±3%F.S	. (25°C)
Tempera	ature accuracy			±2°C ±0.	15×ΔT°C (ΔT: Ambient	temperature - Fluid tei	mperature)	
Repeata	bility				±0.5	%F.S.		
Fluid te	mperature				0°C to 90°C (no fro	eezing and boiling)		
Accurac	y guarantee temp	erature			Fluid temperatu	re: 15°C to 60°C		
Max. w	orking pressure			1MPa(G) @25°C		0.75MPa(G) @25°C	0.65MPa(G) @25°C
Allowab	le ambient temper	ature			0°C to 50°C	(no freezing)		
Allowab	le ambient humidi	ty			95%RH or less (no	dew condensation)		
Storage	temperature				-10°C to 70°C	(no freezing)		
Protecti	ve structure				Equivalent to IP65 (d	rip-proof, dust-proof)		
Material	s of parts in contac	t with liquid			New	PFA		
		Without display	Current: 4	to 20mA, Allowable lo	oad resistance: 250Ω to	500Ω at 24VDC input	, 250Ω or less at 12 VE	OC input or
	Florensta	without display		pulse output (1kHz a	at F.S. Duty: 50%, NPN	open collector output:	Max. 30VDC / 80mA)	
	Flow rate output		Current: 4	to 20mA, Allowable lo	oad resistance: 250Ω to	500Ω at 24VDC input	, 250 Ω or less at 12VE	OC input or
Output		With display		pulse output (1kHz a	at F.S. Duty: 50%, NPN	open collector output:	Max. 30VDC / 80mA)	
Output					Integrated flow ou	ıtput: Pulse output		
	Temperature output			1-5VDC (0°C to 100°C), External	load resistance: 250k	Ω or more	
	(only when water runs)	With display	Current: 4 to 20	mA (0°C to 100 °C), All	lowable load resistance	e: 250Ω to 500Ω at 24\	/DC input, 250Ω or les	s at 12VDC input
	Alarm output			Alarm contacts: 2point	ts NPN open collector o	output, Max. 30VDC / 8	0mA (only with display	()
Digital o	communication			RS48	5 (MODBUS protocol, R	TU mode) (only with d	isplay)	
Power s	upply		12 to	24VDC ±10%, Curren	t consumption (80mA o	or less without display,	140mA or less with d	isplay)
Cable le	ngth				3m terminated, pr	eliminary soldering		
Weight		Without display		160g or less		175g or less	200g or less	360g or less
weigill		With display		165g or less		180g or less	205g or less	365g or less

Ordering



Digital Mass Flow Meter with Display

OWTM MODEL EX-700R SERIES



Gas N₂ (Air, H₂, He, Ar, O₂, CO₂, CH₄ / C.F. switchable) Applicable fluids

Gas 10SCCM to 500SLM Max. flow rate

±1 to 1.5% F.S.

■ Various functions are available with built-in display Instantaneous / integrated flow rate display, gas type switching, C.F. setting, alarm setting, calibration temperature switching, etc

RS485 communication function 4 to 20mA analog output (changeable to 0 to 5VDC and 1 to 5VDC) Integrated flow pulse output


Capable of controlling the flow rate with optional needle valve




Dimensions

Accuracy

F.S.10SCCM to F.S.20SLM




Fittings	Dimension L (mm)
1/4SWL	127.4
1/8SWL	122.8
1/4VCR	123.8
Rc1/4	102




Fittings Dimension L (mm) 157 4 1/4SWI



■ F.S.50, 100, 200SLM




Fittings	Dimension L (mm)
3/8SWL	131.8
1/2VCR	131.4
Rc3/8	112




F.S.50, 100, 200SLM (with precision needle valve)

■ F.S.10SCCM to F.S.20SLM (with precision needle valve)




F.S.300, 400, 500SLM



P-M4 Depth;4

F.S.300, 400, 500SLM (with precision needle valve)



■ D-sub connector (male)



Pin no.	Signal name	Description
1	Power +24V	Power supply +24VDC
2	Power COM	Power COM
3	OUT1	Event output 1
4	OUT2	Event output 2
5	OUT COM	Event output COM
6	Analog flow rate output	Analog flow rate output
7	TR+	RS485 communication
8	TR-	RS485 communication
	Analog flow rate output COM	Analog flow rate output COM
9	TR COM	RS485 communication COM

DC jack

1	2
6	M
(\mathcal{P}
/	


Pin no.	Signal name	Description
1	Power GND	Power GND
2	Power +24V	Power supply +24VDC

Standard Specifications

MODEL		EX-700R	
Sensor type		Thermal sensor	
Applicable gas	N ₂ (Air, H ₂ , He, Ar, O ₂ , CO ₂ , CH ₄ / C.F. switchable)	N ₂ (Air, Ar / C.F. switchable)	N ₂ (Air / C.F. switchable)
Full-scale flow rate (N ₂ equivalent)	10 / 50 / 100 / 500SCCM 1 / 5 / 10 / 20SLM	50 / 100 / 200SLM	300 /400 / 500SLM
Accuracy	±1%F.S.	±	1.5%F.S.
Repeatability		±0.2%F.S.	
Max. inlet pressure		500kPa(G)	
Proof pressure		1MPa(G)	
Allowable ambient temperature		5 to 50°C	
Accuracy guarantee temperature		15 to 35°C	
Allowable storage temperature		-10 to 60°C	
Allowable ambient humidity		10%RH to 90%RH (no dew condensation)	
Materials of parts	SUS316L, SUS316, PTFE, FKN	A (Option: NPP or CP)	SUS316L, SUS316, PTFE, PCTFE,
in contact with gases	303316L, 303316, PTFE, FRI	(Option, NBh of Ch)	FKM (Option: NBR or CR)
Electrical connection		D-sub 9 pins	
Flow rate output signal	4 to 20mA (Load resistance: 500Ω or less) / 0) to 5VDC (Load resistance: $10k\Omega$ or more)	/ 1 to 5VDC (Load resistance: $10k\Omega$ or more
Event output	2 point	s NPN open collector (Max. rating: 30VDC,	50mA)
Digital communication		RS485 (MODBUS protocol, RTU mode)	
Display		4-digit 7-segment LED	
Power supply		24VDC (±10%), 100mA or less	
Fittings	Standard: 1/4SWL type	Standard: 3/8SWL type	Standard: 1/2SWL type
rittings	Option: 1/8SWL type, 1/4VCR type, Rc1/4	Option: 1/2VCR type, Rc3/8	Option: 1/2VCR type, Rc1/2
Weight	Approx. 600g (valve excluded)	Approx. 700g (valve excluded)	Approx. 1,000g (valve excluded)

^{*} Use with a dry and clean gas containing no corrosive components, dust or mist.

Ordering



 $^{^{\}star}$ See Page 45 for the AC adaptor PSK-83CE.

^{*} Accuracy assured with N2 gas.

 $^{^{\}star}$ The full scale of the selected gas is the same as the full scale of $N_{\rm 2}.$

This is gas type correction based on measurement data and does not assure the accuracy.

The customer can register other gas types than registered ones additionally, if their C.F. value is 0.50 to 1.50. For the C.F. value, inquire our office.

^{*} The flow rate output signal can be changed with the display (4 to 20mA at factory default).

The polarity of the AC adaptor differs between the EX-700R and the EX-700. The AC adaptors PSK-85 and PSK-85CE used for the EX-700 are not available for the EX-700R. *See Page 46 for the external cable CP-EX-700-CF.

^{* &#}x27;SWL type' and 'VCR type' are shortened to SW and VCR in Ordering code.

Compact Digital Mass Flow Controller / Mass Flow Meter

MODEL EX-250S SERIES







Applicable fluids Gas N₂, Air, H₂, He, Ar, O₂, CO₂, etc.

Max. flow rate


Gas 5SCCM to 10SLM

±1%F.S. Accuracy

- Compact design
- Within 1sec. response at the entire flow rate control range
- Gas type switchable with rotary switch
- RS485 communication function Analog input / output selectable from 0 to 5VDC or 4 to 20mA Power supply selectable from ±15VDC or 24VDC



Dimensions



Fittings	Dimension L (mm)
Rc1/4	102.0
1/8SWL	122.8
1/4SWL	127.4
1/4VCR	123.8

Wiring connection



Pin no	±15V specification	+24V specification
PIN NO.	Signa	name
1	Valve open /	close input"
2	Flow rat	te output
3	Power +15V	Power +24V
4	Powe	r COM
5	Power -15V	N.C. ⁻²
6	Flow rate set	ting signal Hi"
7	Flow rate output COM	Flow rate output COM Event output COM
8	Flow rate sett	ing signal Lo"
9	N.C. ²	Event output



Pin no.	Signal name
1	TR_COM
2	TR_COM
3	N.C.
4	TR (-)
5	TR (+)
6	N.C.
7	N.C.
8	N.C.

SW1 rotary switch position table

No.	Gas type
0*1*2	User-specified gas
1	N ₂
2	Air
3	H ₂
4	Не
5	Ar
6	Oz
7	CO ₂
8	Unusable
9	User custom C.F. mode (changeable by user)


^{*1.} The C.F. conversion value at ordering time is set *2. Factory default position.

Stanc	lard	Sn	ecifi	cati	ons
Otulio	ulu	OP	COIII	outi	OIII

MODEL	EX-250SC-RJ (MFC)	EX-250SM-RJ (MFM)	
Sensor type	Thermal sensor		
Valve type	Proportional solenoid valve (normally closed)	=	
Applicable gas	N2, AIr, H2, He, Ar, O2, CO2, etc.		
Full-scale flow rate (N ₂ equivalent)	5SCCM to 10SLM		
Control range	2 to 100%F.S.	<u> </u>	
	Within 1sec. (within ±2% F.S.)		
Response	(Within 2sec. for F.S. 5SCCM specification)	-	
	(L: 50 to 149kPa H: 150 to 300kPa)		
Accuracy	±1%F.	S.	
Repeatability	±0.2%	F.S.	
Oti differential	F.S. < 10SLM 50 to 300kPa (Ar CO ₂ : 100 to 300kPa)		
Operating differential pressure	F.S.10SLM 100 to 350kPa (Ar CO2: 150 to 300kPa)	_	
Max. inlet pressure	500kPa	a(G)	
Proof pressure	1MPa(G)		
He Leak rate	≤ 1 × 10 ⁻⁸ Pa⋅m³/s		
Allowable ambient temperature	5 to 50°C		
Accuracy guarantee temperature	15 to 35°C		
Allowable storage temperature	−10 to 60°C		
Allowable ambient humidity	10%RH to 90%RH (no dew condensation)		
	SUS316L, SUS316, Magnetic stainless steel,	SUS316L, SUS316, PTFE,	
Materials of parts in contact with gases	PTFE, FKM (option: NBR or CR)	FKM (option: NBR or CR)	
Florida de la constitución de la	D-sub 9 pins		
Electrical connection	RJ45 connector, 2 pcs		
Florence and a state of the state of	0 to 5VDC (Input impedance: Approx. 1MΩ)		
Flow rate setting signal	or 4 to 20mA (Input impedance: Approx. 250Ω)	_	
Flow rate output signal	0 to 5VDC (Load resistance: 10kΩ or more) or 4 to 20mA (Load resistance: 500Ω or less)		
Event output	1 point NPN open collector (Max. rating: 30VDC, 50mA) (24VDC power specification only)		
Digital communication	RS485		
	+15VDC (±5%) 100mA or less	+15VDC (±5%) 100mA or less	
Power supply	-15VDC (±5%) 150mA or less	-15VDC (±5%) 100mA or less	
	or 24VDC (±10%) 300mA or less	or 24VDC (±10%) 100mA or less	
	Standard: 1/4SWL type		
Fittings	Option: 1/8SWL type, 1	/4VCR type, Rc1/4	
Weight	Approx. 500g	Approx. 440g	

^{*} Use with a dry and clean gas containing no corrosive components, dust or mist. * Accuracy assurance with calibration gas.

Ordering



 $^{^{\}star}$ 'SWL type' and 'VCR type' are shortened to SW and VCR in Ordering code.

^{*} He leak rate does not include permeation.

Leakage (reference value) by long-time permeation is 1 x 10 $^6\mbox{Pa}\cdot\mbox{m}^3/\mbox{sec.}$ or less.

Metal-sealed Digital Mass Flow Controller / Mass Flow Meter

MODEL EX-550 SERIES









Applicable fluids

Gas N₂, Air, H₂, He, Ar, O₂, CO₂, etc.

Max. flow rate

Gas 10SCCM to 5SLM

Accuracy

±1%S.P. (25 to 100%F.S.)

±0.25% F.S. (under 25% F.S.)

- Metal sealing design
- Set-point High-accuracy


Response within 1 sec. at the entire flow rate control range

- Gas type switchable with rotary switch
- RS485 communication function

Analog input / output selectable from 0 to 5VDC or 4 to 20mA Power supply selectable from ±15VDC or 24VDC



Dimensions



Wiring connection







in no.	Signal name
1	TR- (RS485)
2	TR+ (RS485)
3	TRCOM (RS485)

SW1 rotary switch position table

No.	Gas type
0*1*2	User-specified gas
1	N ₂
2	Air
3	H ₂
4	He
5	Ar
6	Oz
7	CO ₂
8	Unusable
9	User custom C.F. mode
9	(changeable by user)


^{*1.} The C.F. conversion value at ordering time is set *2. Factory default position.

Standard Specifications

MODEL	EX-550C (MFC)	EX-550M (MFM)		
Sensor type	Thermal sensor			
Valve type	Proportional solenoid valve (normally closed) —			
Applicable gas	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.			
Full-scale flow rate (N ₂ equivalent)	10SCCM to 5SLM			
Control range	2 to 100%F.S.	_		
Response	Within 1 sec. (within ±2% F.S.)	_		
поропос	(L: 50 to 149kPa H: 150 to 300kPa)			
Accuracy	- 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1	±1%S.P. (25 to 100%F.S.)		
,		inder 25%F.S.)		
Repeatability	±0.2	%F.S.		
Operating differential pressure	50 to 300kPa (Ar CO ₂ : 100 to 300kPa)	_		
Max. inlet pressure	350kPa(G)			
Proof pressure	1MPa(G)			
He Leak rate	$\leq 1 \times 10^{-11} \text{Pa} \cdot \text{m}^3/\text{s}$			
Allowable ambient temperature	5 to 50°C			
Accuracy guarantee temperature	15 to 35°C			
Allowable storage temperature	−10 to 60°C			
Allowable ambient humidity	10%RH to 90%RH (no dew condensation)			
Materials of parts in contact with gases	SUS316L, Magnetic stainless steel, PTFE	SUS316L, PTFE		
Electrical connection	D-sub 9 pins			
Electrical connection	HR-10A × 2			
Flow rate setting signal	0 to 5VDC (Input impedance: Approx. 1M Ω)	_		
riow rate setting signal	or 4 to 20mA (Input impedance: Approx. 250 Ω)	_		
Flow rate output signal	0 to 5VDC (Load resistance: 10kΩ or more)			
Flow rate output signal	or 4 to 20mA (Load resistance: 500Ω or less)			
Digital communication	RS485			
	+15VDC (±5%) 100mA or less	+15VDC (±5%) 100mA or less		
Power supply	-15VDC (±5%) 150mA or less	-15VDC (±5%) 100mA or less		
1-0000000	or 24VDC (±10%) 180mA or less	or 24VDC (±10%) 100mA or less		
Fittings	1/4VC	R type		
Weight	Approx. 800g	Approx. 550g		

 $^{^{\}star}$ Use with a dry and clean gas containing no corrosive components, dust or mist.


Ordering




^{* &#}x27;VCR type' is shortened to VCR in Ordering code.


 $^{^{\}star}$ Accuracy assurance with calibration gas.

Mass Flow Controller / Mass Flow Meter with Display




Dimensions





<<8750 separate type main unit>>



Fittings	Dimension L (mm)
Rc1/4	102
1/4SWL	127.4
1/8SWL	122.8
1/4VCR	123.8

8700


Fittings	Dimension L (mm)
Rc3/8	144
3/8SWL	162.4
1/2SWL	166.4
1/2VCR	163.4

Standard Specifications

MODEL	8700MC / MM	8750MC / MM	
Sensor type	Thermal sensor		
Valve type	Proportional solenoid valve (normally closed)		
Applicable gas	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.		
Full-scale flow rate (N2 equivalent)	10SCCM to 20SLM	30 to 100SLM	
Control range	2 to 100%F.S.	5 to 100%F.S.	
Response	Within 2sec. (within ±2% F.S.)	Within 3sec. (within ±2% F.S.)	
Accuracy	±1%F.S. (25°C)	±1.5%F.S. (25°C)	
Temperature coefficient	±0.1%F.S./°C (15 to 35°C)	±0.2%F.S./°C (15 to 35°C)	
Repeatability	±0.5	%F.S.	
0	F.S. ≤ 5SLM 50 to 300kPa	F.S. ≤ 50SLM 150 to 300kPa	
Operating differential pressure	F.S. > 5SLM 100 to 300kPa	F.S. > 50SLM 200 to 300kPa	
Max. inlet pressure	500kPa(G)		
Proof pressure	1MPa(G)		
He Leak rate	≤ 1 × 10 ⁻⁸ Pa·m³/s		
Allowable ambient temperature	5 to 45°C		
Allowable storage temperature	−10 to 60°C		
Allowable ambient humidity	10%RH to 90%RH (no dew condensation)		
Materials of parts in contact with gases	SUS316, SUS316L, Magnetic stainless steel (MFC only), FKM (option: NBR or CR)		
Electrical connection	D-sub half pitch 20 pins, Hirose DX10M-20S		
Flow rate setting signal	0 to 5VDC (Input impedance: $100k\Omega$ or more) / 4 to 20mA (Input impedance: Approx. 250Ω)		
Flow rate output signal	0 to 5VDC (Load resistance: 250kΩ or more) / 4 to 20mA (Load resistance: 300Ω or less)		
Digital communication	R\$485		
Display	4-digit 7-segment LED		
Power supply	24VDC (±10%),	300mA or less	
Finiana.	Standard: Rc1/4	Standard: Rc3/8	
Fittings	Option: 1/4SWL type, 1/8SWL type, 1/4VCR type	Option: 3/8SWL type, 1/2SWL type, 1/2VCR type	
Weight	Approx. 1,200g	Approx. 1,500g	

^{*} Use with a dry and clean gas containing no corrosive components, dust or mist.

Ordering



^{*} For MP option (100SCCM or more in N_2 equivalent) and LP option (20SLM or less in N_2 equivalent), specify specific pressure conditions.

^{*} Accuracy assurance with calibration gas.

^{*} He leak rate does not include permeation.

Leakage (reference value) by long-time permeation is 1 x 10⁻⁶Pa·m³/sec. or less.

^{*} Analog input/output are changeable with the display (0 to 5VDC at factory default).

^{*} The valve type, control range, respons, operating differential pressure and flow rate setting signal are only for the mass flow controller.

 $^{^{\}star}$ MP option is limited to the use under the specified pressure conditions only. * See Page 45 for the power adaptor PSK-85CE.


See Page 46 for the external cable CP-STD6.

^{* &#}x27;SWL type' and 'VCR type' are shortened to SW and VCR in Ordering code.

Standard Mass Flow Controller



Dimensions




Standard Specifications

MODEL	3660	3665	
Sensor type	Therma	I sensor	
Valve type	Proportional solenoid valve (normally closed)		
Applicable gas	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.		
Full-scale flow rate (N2 equivalent)	10SCCM to 20SLM	30 to 100SLM	
Control range	2 to 100%F.S.	5 to 100%F.S.	
Response	Within 2sec. (within ±2% F.S.)	Within 3sec. (within ±2% F.S.)	
Accuracy	±1%F.S. (25°C)	±1.5%F.S. (25°C)	
Temperature coefficient	±0.1%F.S./°C (15 to 35°C)	±0.2%F.S./°C (15 to 35°C)	
Repeatability	±0.5	%F.S	
Operating differential pressure	F.S. ≤ 5SLM 50 to 300kPa, F.S. > 5SLM 100 to 300kPa F.S. ≤ 50SLM 150 to 300kPa, F.S. > 50SLM 200		
Max. inlet pressure	500kPa(G)		
Proof pressure	1MPa(G)		
He Leak rate	≤ 1 × 10 ⁻⁸ Pa·m³/s		
Allowable ambient temperature	5 to 45°C		
Allowable storage temperature	-10 to 60°C		
Allowable ambient humidity	10%RH to 90%RH (no dew condensation)		
Materials of parts in contact with gases	SUS316L, SUS316, Magnetic stain	less steel, FKM (option: NBR or CR)	
Electrical connection	D-sub 9 pins, KFC standard (compliant with the SEMI standard)		
Flow rate setting signal	0 to 5VDC (Input impe	edance: 1MΩ or more)	
Flow rate output signal	0 to 5VDC (Load resistance: 250kΩ or more)		
Power supply	+15VDC (±5%) 100mA	, -15VDC (±5%) 250mA	
Fittings	Standard: 1/4SWL type, Option: 1/8SWL type, 1/4VCR type, Rc1/4	Standard: 3/8SWL type, Option: 1/2SWL type, 1/2VCR type, Rc3/8	
Weight	Approx. 1,000g	Approx. 1,500g	

^{*} Use with a dry and clean gas containing no corrosive components, dust or mist. * Accuracy assurance with calibration gas.

Ordering



or more in N2 equivalent) and LP option (20SLM or less in N2 equivalent), specify specific pressure conditions. * MP option is limited to the

use under the specified pressure conditions only. * 'SWL type' and 'VCR type' are shortened to SW and VCR in Ordering code.

Wiring connection


■ D-sub 9 pins, KFC standard pin layout (see Fig. 6 on Page 15)

 $^{^{\}star}$ He leak rate does not include permeation. Leakage (reference value) by long-time permeation is 1 x 10 $^{\circ}$ Pa-m $^{\circ}$ /sec. or less.

Standard Mass Flow Meter



Dimensions



Standard Specifications


MODEL	3760	3765		
Sensor type	Thermal sensor			
Applicable gas	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.			
Full-scale flow rate (N2 equivalent)	10SCCM to 20SLM	30 to 100SLM		
Accuracy	±1%F.S. (25°C)	±1.5%F.S. (25°C)		
Temperature coefficient	±0.1%F.S./°C (15 to 35°C)	±0.2%F.S./°C (15 to 35°C)		
Repeatability	±0.5%F.	S. (20°C)		
Max. inlet pressure	500k	500kPa(G)		
Proof pressure	1MPa(G)			
He Leak rate	≤ 1 × 10 ⁻⁸ Pa·m³/s			
Allowable ambient temperature	5 to 45°C			
Allowable storage temperature	−10 to 60°C			
Allowable ambient humidity	10%RH to 90%RH (no dew condensation)			
Materials of parts in contact with gases	SUS316L, FKM (option: NBR or CR)			
Electrical connection	D-sub 9 pins, KFC standard (compliant with the SEMI standard)			
Flow rate output signal	0 to 5VDC (Load resistance: $250k\Omega$ or more)			
Power supply	+15VDC (±5%) 100mA, -15VDC (±5%) 100mA			
Fittings	Standard:1/4SWL type, Option: 1/8SWL type, 1/4VCR type, Rc1/4	Standard:3/8SWL type, Option: 1/2SWL type, 1/2VCR type, Rc3/8		
Weight	Approx. 800g	Approx. 1,000g		

^{*} Use with a dry and clean gas containing no corrosive components, dust or mist.

* Accuracy assurance with calibration gas.

* He leak rate does not include permeation. Leakage (reference value) by long-time permeation is 1 x 10 ePa-m³/sec. or less.


Ordering




Wiring connection

■ D-sub 9 pins, KFC standard pin layout (see Fig. 6 on Page 15)

High-grade Mass Flow Controller



Dimensions




Standard Specifications

MODEL	3200	
Sensor type	Thermal sensor	
Valve type	Proportional solenoid valve (normally closed)	
Applicable gas	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.	
Full-scale flow rate (N2 equivalent)	1SCCM to 20SLM	
Control range	2 to 100%F.S.	
Response	Within 1sec. (within ±2% F.S.)	
Accuracy	±1%F.S.	
Repeatability	±0.2%F.S.	
Operating differential pressure	F.S. ≤ 5SLM 50 to 300kPa, F.S. > 5SLM 100 to 300kPa	
Max. inlet pressure	300kPa(G)	
Proof pressure	1MPa(G)	
He Leak rate	$\leq 1 \times 10^{-8} \text{Pa} \cdot \text{m}^3/\text{s}$	
Allowable ambient temperature	0 to 50°C	
Accuracy guarantee temperature	15 to 35°C	
Allowable storage temperature	−10 to 60°C	
Allowable ambient humidity	10%RH to 90%RH (no dew condensation)	
Materials of parts in contact with gases	SUS316L, Ni, PTFE, FKM (option: NBR or CR)	
Electrical connection	D-sub 9 pins, KFC standard (compliant with the SEMI standard)	
Flow rate setting signal	0 to 5VDC (Input impedance: 1MΩ or more)	
Flow rate output signal	0 to 5VDC (Load resistance: 250kΩ or more)	
Power supply	+15VDC (±5%) 100mA, -15VDC (±5%) 200mA	
Fittings	Standard: 1/4SWL type, Option: 1/8SWL type, 1/4VCR type, Rc1/4	
Weight	Approx. 1,000g	

^{*} Use with a dry and clean gas containing no corrosive components, dust or mist.

* Accuracy assurance with calibration gas.

Ordering




- * For MP option (100SCCM or more in N₂ equivalent) and LP option (20SLM or less in N₂ equivalent), specify specific pressure conditions.
- * MP option is limited to the use under the specified pressure conditions only.
- *For SR option, only operation check is conducted as to measurement points except for 100% F.S. in the case of the gas type of SSCCM or less in calibration gas equivalent.
- to SW and VCR in Ordering code.

Wiring connection


■ D-sub 9 pins, KFC standard pin layout (see Fig. 6 on Page 15)

 $^{^{\}star}$ He leak rate does not include permeation. Leakage (reference value) by long-time permeation is 1 x 10 6 Pa-m 3 /sec. or less than 10 6 Pa-m 3 /sec.

High-grade Mass Flow Meter



Dimensions




Standard Specifications

MODEL	3100	
Sensor type	Thermal sensor	
Applicable gas	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.	
Full-scale flow rate (N2 equivalent)	1SCCM to 20SLM	
Accuracy	±1%F.S.	
Repeatability	±0.2%F.S.	
Max. inlet pressure	500kPa(G)	
Proof pressure	1MPa(G)	
He Leak rate	$\leq 1 \times 10^{-8} \text{Pa} \cdot \text{m}^3/\text{s}$	
Allowable ambient temperature	0 to 50°C	
Accuracy guarantee temperature	15 to 35°C	
Allowable storage temperature	−10 to 60°C	
Allowable ambient humidity	10%RH to 90%RH (no dew condensation)	
Materials of parts in contact with gases	SUS316L, Ni, PTFE, FKM (option: NBR or CR)	
Electrical connection	D-sub 9 pins, KFC standard (compliant with the SEMI standard)	
Flow rate output signal	0 to 5VDC (Load resistance: 250kΩ or more)	
Power supply	+15VDC (±5%) 100mA, -15VDC (±5%) 100mA	
Fittings	Standard: 1/4SWL type, Option: 1/8SWL type, 1/4VCR type, Rc1/4	
Weight	Approx. 800g	

^{*} Use with a dry and clean gas containing no corrosive components, dust or mist.
* Accuracy assurance with calibration gas.

Ordering




- * For SR option, only operation check is conducted as to measurement points except for 100% F.S. in the case of the gas type of 3SCCM or less in calibration gas equivalent.
- * 'SWL type' and 'VCR type' are shortened to SW and VCR in Ordering code.

Wiring connection


■ D-sub 9 pins, KFC standard pin layout (see Fig. 6 on Page 15)

^{*} He leak rate does not include permeation. Leakage (reference value) by long-time permeation is 1 x 10 ePa-m³/sec. or less.

Metal-sealed Mass Flow Controller



Dimensions




Standard Specifications

MODEL	5100	
Sensor type	Thermal sensor	
Valve type	Proportional solenoid valve (normally closed)	
Applicable gas	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.	
Full-scale flow rate (N2 equivalent)	1SCCM to 20SLM	
Control range	2 to 100%F.S.	
Response	Within 1sec. (within ±2% F.S.)	
Accuracy	±1%F.S.	
Repeatability	±0.2%F.S.	
Operating differential pressure	F.S.≤5SLM 50 to 300kPa, F.S.>5SLM 100 to 300kPa	
Max. inlet pressure	300kPa(G)	
Proof pressure	1MPa(G)	
He Leak rate	≤1 × 10 ⁻¹¹ Pa·m³/s	
Allowable ambient temperature	0 to 50°C	
Accuracy guarantee temperature	15 to 35°C	
Allowable storage temperature	-10 to 60°C	
Allowable ambient humidity	10%RH to 90%RH (no dew condensation)	
Materials of parts in contact with gases	SUS316L, Ni, PTFE, Au	
Electrical connection	D-sub 9 pins, KFC standard (compliant with the SEMI standard)	
Flow rate setting signal	0 to 5VDC (Input impedance: $1M\Omega$ or more)	
Flow rate output signal	0 to 5VDC (Load resistance: 250kΩ or more)	
Power supply	+15VDC (±5%) 100mA, -15VDC (±5%) 200mA	
Fittings	1/4VCR type	
Weight	Approx. 1,000g	

 $^{^{\}star}$ Use with a dry and clean gas containing no corrosive components, dust or mist.

Ordering



^{*} For MP option (100SCCM or more in N_2 equivalent) and LP option (20SLM or less in N_2 equivalent), specify specific pressure conditions.

Wiring connection

■ D-sub 9 pins, KFC standard pin layout (see Fig. 6 on Page 15)


^{*} Accuracy assurance with calibration gas

^{*} MP option is limited to the use under the specified pressure conditions only.


^{*} For SR option, only operation check is conducted as to measurement points except for 100% F.S. in the case of the gas type of 3SCCM or less in calibration gas equivalent.

^{* &#}x27;VCR type' is shortened to VCR in Ordering code

Metal-sealed Mass Flow Meter



Dimensions




Standard Specifications

MODEL	5410	
Sensor type	Thermal sensor	
Applicable gas	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.	
Full-scale flow rate (N₂ equivalent)	10SCCM to 20SLM	
Accuracy	±1%F.S.	
Repeatability	±0.2%F.S.	
Max. inlet pressure	500kPa(G)	
Proof pressure	1MPa(G)	
He Leak rate	≤1 × 10 ⁻¹¹ Pa·m³/s	
Allowable ambient temperature	0 to 50°C	
Accuracy guarantee temperature	15 to 35°C	
Allowable storage temperature	-10 to 60°C	
Allowable ambient humidity	10%RH to 90%RH (no dew condensation)	
Materials of parts in contact with gases	SUS316L, Ni, PTFE	
Electrical connection	D-sub 9 pins, KFC standard (compliant with the SEMI standard)	
Flow rate output signal	0 to 5VDC (Load resistance: 250kΩ or more)	
Power supply	+15VDC (±5%) 100mA, -15VDC (±5%) 100mA	
Fittings	1/4VCR type	
Weight	Approx. 800g	

 $^{^{\}star}$ Use with a dry and clean gas containing no corrosive components, dust or mist.

Ordering



^{* &#}x27;VCR type' is shortened to VCR in Ordering code.

Wiring connection


■ D-sub 9 pins, KFC standard pin layout (see Fig. 6 on Page 15)

^{*} Accuracy assurance with calibration gas.

Low-cost Mass Flow Meter with Display

Applicable fluids Gas N₂, Air, H₂, He, Ar, O₂, CO₂, etc. Max. flow rate Gas 10SCCM to 100SLM Accuracy ±2 to 3%F.S. Various functions are available with built-in display Instantaneous / integrated flow rate display, alarm setting Analog output selectable from 4 to 20mA or 1 to 5VDC Integrated flow pulse output Capable of controlling the flow rate with optional needle valve

Dimensions




Standard Specifications

MODEL	3810DSII		
Sensor type	Thermal sensor		
Applicable gas	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.		
Full-scale flow rate (N₂ equivalent)	10SCCM to 20SLM	21 to 100SLM	
Accuracy	±2%F.S. (25°C)	±3%F.S. (25°C)	
Temperature coefficient	±0.2%F.S./°C	(15 to 35°C)	
Max. inlet pressure	500kl	Pa(G)	
Proof pressure	1MPa(G)		
Allowable ambient temperature	0 to 50°C		
Allowable storage temperature	-10 to 60°C		
Allowable ambient humidity	30%RH to 80%RH (no dew condensation)		
Materials of parts in contact with gases	SUS303, PTFE, FKM (option: NBR or CR)		
Electrical connection	Hirose HR10A-7R-6P (HR10A-7P-6S on cable side)		
Flow rate output signal	1 to 5VDC or 4 to 20mA		
Event output	2 points NPN open collector (Max. rating: 30VDC, 50mA)		
Display	4-digit 7-segment LED		
Power supply	24VDC (±5%) 100mA		
Fittings	Rc1/4		
Weight	Approx. 400g (valve excluded)		

^{*} Use with a dry and clean gas containing no corrosive components, dust or mist.

Ordering




^{*} See Page 45 for the power adaptor PSK-38DSII.


^{*} Accuracy assurance with calibration gas.

^{*} See Page 46 for the external cable CP-3810DSII-CF.

Low-cost Mass Flow Sensor



Dimensions




Standard Specifications

MODEL	3810S		
Sensor type	Thermal sensor		
Applicable gas	N ₂ , Air, H ₂ , He, Ai	r, O ₂ , CO ₂ , etc.	
Full-scale flow rate (N2 equivalent)	10SCCM to 2SLM	3 to 50SLM	
Accuracy	±3%F.S. (25°C)	±5%F.S. (25°C)	
Temperature coefficient	±0.15%F.S./°C (15 to 35°C)	±0.2%F.S./°C (15 to 35°C)	
Repeatability	±0.5%	F.S.	
Max. inlet pressure	500kPa(G)		
Proof pressure	1MPa(G)		
Allowable ambient temperature	5 to 45°C		
Allowable storage temperature	-10 to 60°C		
Allowable ambient humidity	10%RH to 90%RH (no dew condensation)		
Materials of parts in contact with gases	SUS303, PTFE, FKM (option: NBR or CR)		
Electrical connection	AMP 171826-5 (171822-5 on cable side)		
Flow rate output signal	0 to 5VDC (Load resistance: 250kΩ or more)		
Power supply	+15VDC (±5%) 60mA, -15VDC (±5%) 60mA		
Fittings	Rc1/4		
Weight	Approx. 250g Approx. 350g		

^{*} Use with a dry and clean gas containing no corrosive components, dust or mist.

Ordering



Cable connection

No.1	Power supply: +15VDC
No.2	Power COM
No.3	Power supply: -15VDC
No.4	Flow rate output: 0 to 5VDC
No.5	Flow rate output COM

^{*} Accuracy assurance with calibration gas.

Large flow rate Mass Flow Controller

DEL HFC-303 SERIES

MFC

Applicable fluids Gas N₂, Air, H₂, He, Ar, O₂, CO₂, etc.


Gas 100 to 1000SLM Max. flow rate

±1%F.S. Accuracy

■ Available for large flow rates (F.S. 1,000SLM in N₂ equivalent)



Dimensions



≤300SLM 1/2SWL typ	oe
HFC-303 1/2"FITTING	i
FITTING TYPE	SWAG. 1/2" W NUT
DIM "A"	7.56 (197.6)
DIM "B"	5.36 (136.1)
DIM "C"	1.36 (34.5)

>300SLM 3/4SWL type				
ì				
SWAG. 3/4" W NUT				
8.44 (214.4)				
5.76 (146.3)				
1.56 (39.6)				

Standard Specifications

MODEL	HFC-303		
Sensor type	Thermal sensor		
Valve type	Proportional solenoid + pneumati	ic 2-stage valve (normally closed)	
Applicable gas	N ₂ , Air, H ₂ , He,	Ar, O ₂ , CO ₂ , etc.	
Full-scale flow rate (N2 equivalent)	100 to 300SLM	301 to 1000SLM	
Control range	2 to 100%F.S.	5 to 100%F.S.	
Accuracy	±1%F.S	. (25°C)	
Temperature coefficient	±0.1%F.S./°C (15 to 35°C)	±0.2%F.S./°C (15 to 35°C)	
Repeatability	±0.25	5%F.S.	
Operating differential pressure	Individually processed		
Proof pressure	3.4MPa(G) (HP option: 6.8MPa(G))		
He Leak rate	≤1 × 10 ⁻⁷ Pa·m³/s		
Allowable ambient temperature	5 to 45°C		
Allowable storage temperature	-10 to 60°C		
Allowable ambient humidity	10%RH to 90%RH (no dew condensation)		
Materials of parts in contact with gases	SUS316, Ni, SUS302, FKM		
Electrical connection	D-sub 15 pins		
Flow rate setting signal	0 to 5VDC (Input impedance: 1MΩ or more)		
Flow rate output signal	0 to 5VDC (Load resistance: 250kΩ or more)		
Power supply	+15VDC (±5%) 150mA, -15VDC (±5%) 300mA		
Fittings	1/2SWL type 3/4SWL type		
Weight	Approx. 2,400q		

- * Use with a dry and clean gas containing no corrosive components, dust or mist.

 * Accuracy assurance with calibration gas.

 * He leak rate does not include permeation. Leakage (reference value) by long-time permeation is 1 × 10 *Pa·m³/sec. or less.

 * The material of the gas contact part is subject to change, depending on the specification.

 * In order to measure the flow rate accurately, attach straight pipes to inlet and out of the unit, which has the same diameter as the piping diameter. Particularly, longer than 300mm straight pipe is recommended for the inlet side.

Ordering

MODEL Fittings	Fluid	Full-scale flow rate	Calibration temperature	Supply pressure	Outlet pressure	Option
HFC-303 1/2SWL type 3/4SWL type						HP: High pressure
HFC-303 1/2SW	N ₂	100SLM	20°C	0.1MPa	0MPa	

^{* &#}x27;SWL type' is shortened to SW in Ordering code


Wiring connection (D-sub 15 pins)

Pin no.	Signal name	Pin nc.	Signal name	Pin no.	Signal name
1	NC	6	Output signal: 0V to 5V	11	Power supply: +15VDC
2	NC	7	NC	12	Power COM
3	NC	8	Valve open / close	13	NC
4	NC	9	Power supply: -15VDC	14	Flow rate setting
5	Signal COM	10	NC	15	NC

Large flow rate Mass Flow Meter



Dimensions



≤300SLM 1/2SWL type HFM-301 1/2FITTING		
DIM "A"	6.31 (165.9)	
DIM "B"	4.11 (104.4)	
DIM "C"	1.36 (34.5)	


>300SLM 3/4SWL type		
HFM-301 3/4FITTING		
FITTING TYPE	SWAG. 3/4" W NUT	
DIM "A"	6.99 (177.5)	
DIM "B"	4.31 (109.5)	
DIM "C"	1.56 (39.6)	

Standard Specifications

MODEL	HFM-301			
Sensor type	Thermal sensor			
Applicable gas	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.			
Full-scale flow rate (N2 equivalent)	100 to 300SLM 301 to 1000SLM			
Accuracy	±1%F.S. (25°C)			
Temperature coefficient	±0.1%F.S./°C (15 to 35°C) ±0.2%F.S./°C (15 to			
Repeatability	±0.25%F.S.			
Proof pressure	3.4MPa(G) (HP option: 6.8MPa(G))			
He Leak rate	≤1 × 10 ⁻⁷ Pa·m³/s			
Allowable ambient temperature	5 to 45°C			
Allowable storage temperature	-10 to 60°C			
Allowable ambient humidity	10%RH to 90%RH (no dew condensation)			
Materials of parts in contact with gases	SUS316, Ni, SUS302, FKM			
Electrical connection	D-sub 15 pins			
Flow rate output signal	0 to 5VDC (Load resistance: 250kΩ or more)			
Power supply	+15VDC (±5%) 60mA, -15VDC (±5%) 60mA			
Fittings	1/2SWL type	3/4SWL type		
Weight	Approx. 1,600g			

- * Use with a dry and clean gas containing no corrosive components, dust or mist.
 * Accuracy assurance with calibration gas
- * He leak rate does not include permeation. Leakage (reference value) by long-time permeation is 1 \times 10 $^{\circ}$ Pa·m 3 /sec. or less.
- * The material of the gas contact part is subject to change, depending on the specification.

Ordering



^{* &#}x27;SWL type' is shortened to SW in Ordering code.

Wiring connection (D-sub 15 pins)

Pin no.	Signal name	Pin no.	Signal name	Pin no.	Signal name
1	NC	6	Output signal: 0V to 5V	11	Power supply: +15VDC
2	NC	7	NC	12	Power COM
3	NC	8	NC	13	NC
4	NC	9	Power supply: -15VDC	14	NC
5	Signal COM	10	NC	15	NC

^{*} In order to measure the flow rate accurately, attach straight pipes to inlet and out of the unit, which has the same diameter as the piping diameter. Particularly, longer than 300mm straight pipe is recommended for the inlet side.

Low pressure drop large flow rate Mass Flow Meter

MODEL HFM-200W / LS SERIES



Applicable fluids Q_{as} N_2 , Air, H_2 , He, Ar, O_2 , CO_2 , etc.

Max. flow rate Gas 1500 to 15000SLM

Accuracy ±3 to 5% F.S.

■ Available for large flow rates (F.S. 15,000SLM in N₂ equivalent)



Standard Specifications


MODEL	HFM-200W / LS			
Sensor type	Thermal sensor			
Applicable gas	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.			
Full-scale flow rate (N2 equivalent)	1500SLM	3000SLM	6000SLM	15000SLM
Accuracy	±3%F.S. (25°C)		±5%F.S. (25°C)	
Temperature coefficient	±0.1%F.S./°C (15 to 35°C)		±0.2%F.S./°C (15 to 35°C)	
Repeatability	±0.5%F.S.			
Proof pressure	980kPa(G) (Smooth end: 3.4 MPa(G))			
He Leak rate	<1 × 10 ⁻⁷ Pa·m³/s			
Allowable ambient temperature	5 to 45°C			
Allowable storage temperature	-10 to 60°C			
Allowable ambient humidity	10%RH to 90%RH (no dew condensation)			
Materials of parts in contact with gases	SUS316, Ni, FKM			
Electrical connection	D-sub 15 pins			
Flow rate output signal	0 to 5VDC (Load resistance: 250kΩ or more)			
Power supply	+15VDC (±5%) 50mA, -15VDC (±5%) 50mA			
Fittings	Standard: 3" NPT	Standard: 4" Ansi flange	Standard: 6" Ansi flange	Standard: 8" Ansi flange
	Option: 3" smooth end	Option: 4" smooth end	Option: 6" smooth end	Option: 8" smooth end

^{*} Use with a dry and clean gas containing no corrosive components, dust or mist.

Laminar flow element

Laminar type	Connection	Laminar type	Connection
3	3" NPT	6F	6" Ansi flange
3S	3" smooth end (option)	6S	6" smooth end (option)
4F	4" Ansi flange	8F	8" Ansi flange
4S	4" smooth end (option)	8S	8" smooth end (option)

Ordering



Wiring connection (D-sub 15 pins)

Pin no.	Signal name	Pin nc.	Signal name	Pin no.	Signal name
1	NC	6	Output signal: 0V to 5V	11	Power supply: +15VDC
2	NC	7	GND	12	Power COM
3	NC	8	NC	13	NC
4	NC	9	Power supply: -15VDC	14	NC
5	Signal COM	10	NC	15	NC

^{*} Accuracy assurance with calibration gas.

 $^{^{\}star}$ He leak rate does not include permeation. Leakage (reference value) by long-time permeation is 1 \times 10 $^{\circ}$ Pa·m $^{\circ}$ /sec. or less.

^{*} The material of the gas contact part is subject to change, depending on the specification.

^{*} In order to measure the flow rate accurately, attach straight pipes to inlet and out of the unit, which is longer than 5 times of the laminar diameter.


Handy Mass Flow Control / Measuring Unit



■ Handy mass flow control / measuring unit combining the readout unit CR-400B with the mass flow controller / mass flow meter



Dimensions




- * For L, refer to the face-to-face dimension of each MFC / MFM.
- * "FLOW COMPO™" is our registered trademark

Standard Specifications

MODEL	FCC4000-3660	FCC4000-3200	FCM4000-3760	FCM4000-3100
Equipped MFC / MFM	3660 (MFC)	3200 (MFC)	3760 (MFM)	3100 (MFM)
Full-scale flow rate (N2 equivalent)	10SCCM to 20SLM	1SCCM to 20SLM	10SCCM to 20SLM	1SCCM to 20SLM
Accuracy	±1%F.S. (25°C)	±1%F.S. (15 to 35°C)	±1%F.S. (25°C)	±1%F.S. (15 to 35°C)


 $^{^{\}star}$ For the detailed specifications, refer to equipped MFC / MFM. For CR-400B, inquire our sales office.

Ordering




^{* &#}x27;SWL type' and 'VCR type' are shortened to SW and VCR in Ordering code.

Small Karman Vortex Flow Meter for Liquid



Dimensions




MODEL	FM0101	FM0102	FM0103	FM0105
Dimension (a)	17.8	17.8	17.8	32.5
Dimension (L)	80.6	80.0	80.0	110.0

- * Unspecified outer dimension tolerance: ±0.8
- Dimension tolerance for other than unspecified outer dimensions: ± 0.4
- * Do not apply an excessive tightening torque to the main body and mounting screws because they are made of resin

Standard Specifications


MODEL			FM0101	FM0102	FM0103	FM0105	
(Connection) X			R3/8	R1/2	R1/2	25A (Equivalent to 35A piping	
Flow rate range			0.5 to 4L/min	2 to 16L/min	4 to 40L/min	10 to 150L/min	
Fluid	uid Water						
Accurac	у		±3%F.S. (25°C)				
Repeata	bility			±0.59	%F.S.		
Liquid te	emperature			0 to 7	70°C		
Proof pr	essure			1MP	a(G)		
Allowabl	wable ambient temperature 0 to 50°C						
Allowable ambient humidity 5%RH to 90%RH (no dew condensation)							
Protective structure			IP64 (JIS C0920 Splash-proof structure)				
Materials of parts in contact with liquid		th liquid	PPS/30% mixture of glass, FKM			PPS, FKM	
			Display: 3-digit LED				
	With display	D	Current output: 4 to 20mA (linear)				
Output			Alarm output: Open collector (2 LEDs, 80mA, 30VDC at maximum)				
	Mildon dinata	S	Current output: 4 to 20mA (linear)				
	Without display	Р	Pulse outpu	t: Open collector (10mA, 30VDC at	maximum)	-	
Supply v	roltage		12 to 24VDC				
Cabla la	n akh		Without display: 2m terminated, preliminary soldering				
Cable le	ngui		With display: 3m terminated, preliminary soldering				
Woight				Without display: 60g (main body)		165g (main body)	
Weight				With display: 100g (main body)		205g (main body)	

Ordering



 $^{^{\}star}$ For the FM0105, union nuts, sockets and O-rings for connection are available as option.


Small Karman Vortex Flow Meter for Liquid



Standard Specifications

MODEL			FM3101	FM3102	FM3103	FM3104		
Connecti	ion		3/8" tube end	1/2" tube end	3/4" tube end	1" tube end		
Flow rate	e range		0.4 to 4L/min	2 to 20L/min	5 to 50L/min	10 to 100L/min		
Fluid	d Pure water, chemical solution							
Accuracy	1			±3%F.S.	(25°C)			
Repeatal	bility			±0.5%	%F.S.			
Liquid te	mperature			0°C to 90°C (no free	ezing and boiling)			
Proof pre	essure			1MPa	a(G)			
Allowable	e ambient temperati	ure	0 to 50°C					
Allowable	owable ambient humidity 5%RH to 90%RH (no dew condensation)				dew condensation)			
Protectiv	re structure			IP64 (JIS C0920 Spla	ash-proof structure)			
Materials	of parts in contact wi	ith liquid	New PFA, Super PFA					
			Display: 3-digit LED					
Output	With display	D	Current output: 4 to 20mA (linear)					
Output				Alarm output: Open collector (2 LE	EDs, 80mA, 30VDC at maximum)			
	Without display	S		Current output: 4 to 20mA (linear)				
Supply v	oltage		12 to 24VDC					
Cable lor	agth		Without display: 2m terminated, preliminary soldering					
Cable ler	igui		With display: 3m terminated, preliminary soldering					
Woight				Without display: 60g (main body)		165g (main body)		
Weight				With display: 100g (main body)		205g (main body)		


Ordering



Ultrasonic Flow Meter for Liquid



Dimensions



Standard Specifications

MODEL	FML-500	
end.	Water, pure water (no air bubbles)	
Fluid	* For other liquids, please contact us.	
Fluid sound velocity	1300 to 1600m/s	
Fluid temperature range	15 to 50°C	
Measurement range	0 to 5L/min	
Accuracy	See Table 1.	
Materials of parts in contact with liquid	New PFA	
Proof pressure	0.5MPa (at 23°C)	
Process connection	6mm tube end	
Exclusive cable length	3m	
Cable sheath	PVC	
Structure	Equivalent to IP64	
Allowable ambient temperature	5°C to 50°C (no dew condensation)	
Allowable ambient humidity	10%RH to 85%RH (no dew condensation)	
Mounting direction	Vertical, horizontal, oblique	
Weight	200g (main body)	


Table 1. Accuracy (Water, 23°C)

Measurement range		0 to 5L/min		
Flow rate range		0-0.20L/min to 0-5.00L/min		
Accuracy	2	Less than 1m/s	±30mL/min (Less than 0.8L/min)	
	Flow	1 to 2m/s	±2.5%F.S. (0.8 to 1.5L/min)	
	velocity	2 to 3m/s	±2.0%F.S. (1.6 to 2.2L/min)	
	Sity	3 to 6.6m/s	±1.5%F.S. (2.3 to 5L/min)	

Electrical specifications

Measuring method		Ultrasonic propagation time difference calculation method
0	1) Flow rate output	4 to 20mA (load resistance: 500Ω or less)
0utput	2) Flow rate alarm output	2 points open collector output Load rating: 30VDC, 20mA, Operation: Comparison method
Display		4-digit 7-segment LED
Dis	splay data	Instantaneous flow rate, integrated flow rate
Ala	arm output monitor	2-point LED display (instantaneous flow rate alarm, integrated flow rate alarm)
Parameter setting Power supply Current consumption		With 4 key switches on the panel
		24VDC±5%
		Current consumption 150mA or less

Ordering




Compact Readout Unit

MODEL CR-400B

- Power supply combining flow rate setting and display for mass flow controller / mass flow meter
- Capable of using various functions by operating the display (Instantaneous / integrated flow rate display, alarm setting, valve open / close of mass flow controller, etc.)
- External operation allowed by RS485 communication function and analog input / output of 0 to 5VDC



Dimensions



(Panel cutting dimensions)

1.4mm to 1.5mm when 1 accessory washer is set between the main body and the bracket.


1.6mm to 2.0mm when 2 accessory washers are set between the main body and the bracket.

Standard Specifications

MODEL	CR-400B
Control function	Flow setting, forced valve open / close operation and zero cut
Flow rate input / output signal	0 to 5VDC
Power output	±15VDC (300mA)
Display	4-digit 7-segment LED (4 digits for instantaneous flow rate, 8 digits for integrated flow rate (upper and lower 4 digits shown alternately)
Display accuracy	Instantaneous flow rate: within ±0.1% F.S., ±1 digit
	D-sub 9 pins, female (on MF main body side)
Electrical connection	D-sub half pitch, 20 pins, female (external control)
Format and and	2 stages (select from among upper-limit, lower-limit, upper and lower-limit instantaneous flow rates, and arrival of integrated flow rate)
Event output	Open collector output (max. rating: 50V, 50mA)
Digital communication	RS485
Power consumption	Approx. 25W
Input voltage (frequency)	85 to 264VAC (48 to 440Hz)
Power cable	Approx. 3m
Weight	Approx. 400g

^{*} The flow rate setting function is valid only for the mass flow controller.

Ordering



 $^{^{\}star}$ See Page 46 for the mass flow controller / mass flow meter connection cables CP-STD1 and CP-STD5, and the external cable CP-STD6.

 $^{^{\}star}$ The old models of mass flow controllers / mass flow meters may not operate properly, or their specific functions may fail.

Power Supply for Mass Flow Controller / Mass Flow Meter

MODEL PSK-FB SERIES

- Power supply for mass flow controller / mass flow meter
- Capable of supplying the power for 1 system with 1FB, for 3 systems with 3FB and for 6 systems with 6FB




PSK-1FB







one

Dimensions







Standard Specifications

MODEL		PSK-1FB	PSK-3FB	PSK-6FB		
Power s	upply for	1 unit	3 units	6 units		
F1 - 1 - 1 - 1		D-s	ub 9 pins, female (on MF main body side)			
Electrica	al connection	D-si	ub 15 pins, female (on display and setting device s	ide)		
Input vo	Itage (frequency)		85 to 132VAC (47 to 66Hz)			
Power c	onsumption	Up to 22W	Up to 22W Up to 70W Up to 140W			
Fuse		125V-0.8A	125V-3.15A	125V-6.3A		
	Power output	±15VDC (±5%)				
Output	For flow rate setting		+5VDC (±1%)			
	For external display		+5VDC (±5%),+15VDC (±5%)			
Flow rat	e input / output signal	0 to 5VDC, up to 15VDC				
Flow rat	e setting output signal		0 to 5VDC			
Working temperature		0 to 40°C				
Working environment		0%RH to 90%RH (no dew condensation)				
Weight		Approx. 800g	Approx. 1,300g	Approx. 1,700g		

AC Adapter for Mass Flow Controller / Mass Flow Meter

SK-83CE / PSK-85CE

- PSK-83CE available for Model EX-700R series
- PSK-85CE available for Model 8700 series





Ordering

- Power adaptor: PSK-83CE (cable length: approx. 1,500mm)
- Power adaptor: PSK-85CE (cable length: approx. 1,200mm)

AC Adapter for Mass Flow Meter

SK-38DSII

■ PSK-38DSII available for Model 3810DSII series





Ordering

■ Power adaptor: PSK-38DSII (cable length: approx. 1,900mm)

Conversion Plug


TR-AD

А	BF	SE	С	В3	0
a		SE SE	O	100	0
TR-AD11	TR-AD12	TR-AD13	TR-AD14	TR-AD15	TR-AD16


Table of compatibility Cables and accessories for mass flow controller / mass flow meter

Examples of using the accessories


■ When using the power unit PSK-FB series



■ When using the CR-400B



(Ordering method: Main unit to power supply)



STD1 : D-sub 9 pins (compliant with SEMI std.)
STD5 : D-sub 15 pins (HFC and HFM series)

(Example) When ordering 1m length cable to connect 3660 and CR-400B : CP-STD-1M

(Ordering method: CR-400B external input / output)



List of applicable cables

MODEL	Shape	Applicable model and usage	
CP-STD1-1M	D-sub 9P on both ends, 1m	EV 2505 EV 550 2660 2200 5410 5100	
CP-STD1-3M	D-sub 9P on both ends, 3m	EX-250S, EX-550, 3660, 3200, 5410, 510	
CP-STD1-5M	D-sub 9P on both ends, 5m	3100, 3700, to PSK-FB / CK-400B	
CP-STD5-1M	D-sub 15P / 9P, 1m	HEC 202 HEM 201 HEM 200W/15	
CP-STD5-3M	D-sub 15P / 9P, 3m	HFC-303, HFM-301, HFM-200W / LS, to PSK-FB / CR-400B	
CP-STD5-5M	D-sub 15P / 9P, 5m	10 F3K-FB / CK-400B	
CP-STD6-1M	D-sub 20P / loose end, 1m		
CP-STD6-3M	D-sub 20P / loose end, 3m	8700 and CR-400B input / output cable	
CP-STD6-5M	D-sub 20P / loose end, 5m		
CC-STD1-1M	D-sub 15P / AM pins, 1m	Overall Mass Flow products (±15 VDC)	
CC-STD1-3M	D-sub 15P / AM pins, 3m	Between PSK-FB and display	
CC-STD1-5M	D-sub 15P / AM pins, 5m	Detween F3K-1 B and display	
CP-3810DSII-CF-1M	HRS 6P / loose end, 1m	3810DSII exclusive free cable	
CP-3810DSII-CF-3M	HRS 6P / loose end, 3m	Round connector	
CP-3810DSII-CF-5M	HRS 6P / loose end, 5m	(HR10A-7P-6S)	
CP-EX-700-CF-1M	D-sub 9P / loose end, 1m	EX-250S, EX-550, EX-700R	
CP-EX-700-CF-3M	D-sub 9P / loose end, 3m	24VDC conditions	
CP-EX-700-CF-5M	D-sub 9P / loose end, 5m	24VDC conditions	
CT-DF3-0.3M	HRS 4P on both ends, 0.3m	EX-550	
CT-DF3-1M	HRS 4P on both ends, 1m	Communication cable	
CT-DF3-3M	HRS 4P on both ends, 3m	Round connector	
CT-DF3-5M	HRS 4P on both ends, 5m	(HR10A-7P-4P)	

 $^{^{\}star}$ The RJ connector standard used for the EX series is "RJ45."



List of Variable Flow Meter



















Fluids





control valve

control valve













List of Variable Flow Meter












About Variable Flow Meter

Principle of flow meter

As shown in the ${\it figure\ below},$ the variable flow meter contains a float in a conical cylinder (tapered tube) whose upper end spread wider than the lower end. The float moves up/down depending on a degree of flow rate, reading a balanced position to obtain the flow



Now, the symbols and units are determined as follows.

- Vf: Volume of the float [cm3]
- of: Density of the float [q/cm3]
- af: Max. cross-sectional area of the float [cm²]
- P₁: Pressure right under the float [Pa]
- P2: Pressure right above the float [Pa]
- ρ: Density of the fluid [g/cm³]
- U1: Flow velocity right under the float [cm/sec]
- U2: Flow velocity in the gap with the float [cm/sec]
- A₁: Cross-sectional area right under the float [cm²]
- A2: Cross-sectional area of the gap with the float [cm²]
- Q: Flow rate [cm³/sec]
- g: Acceleration of gravity

A float push-up force is af(P₁ - P₂). By subtracting buoyancy, the gravity of the float is $Vf(\rho f - \rho)g$.

The balance formula is;

$$af(P_1 - P_2) = Vf(\rho f - \rho)g$$

$$P_1 - P_2 = \frac{Vf(\rho f - \rho)g}{af}$$
 (1)

Now, based on the flow rate $Q = A_1U_1 = A_2U_2$;

$$U_1 = \frac{Q}{A_1}$$
 $U_2 = \frac{Q}{A_2}$ (2)

Now, based on Bernoulli's theorem;

$$\frac{{{U_1}^2}}{2} + \frac{{{P_1}}}{\rho } = \frac{{{U_2}^2}}{2} + \frac{{{P_2}}}{\rho }$$

$$P_1 - P_2 = \frac{\rho}{2} (U_2^2 - U_1^2)$$
(3)

Substitute (2) for (3).

$$P_1 - P_2 = \frac{\rho}{2} \left[\left(\frac{Q}{A_2} \right)^2 - \left(\frac{Q}{A_1} \right)^2 \right]$$
 Solve this formula.

$$Q = \frac{A_1 A_2}{\sqrt{A_1^2 - A_2^2}} \sqrt{\frac{2(P_1 - P_2)}{\rho}}$$
 (4)


Substitute "P1 - P2" of (1) for this

$$Q = \frac{A_1 A_2}{\sqrt{|A_1|^2 - A_2|^2}} \sqrt{\frac{2g(\rho f - \rho)}{\rho} \cdot \frac{Vf}{af}}$$

Actually, there is a friction resistance and a general formula will be as follows.

Q = C
$$\frac{A_1 A_2}{\sqrt{A_1^2 - A_2^2}} \sqrt{2g \left(\frac{\rho f - \rho}{\rho}\right) \cdot \frac{Vf}{af}}$$
(5)

 $A_1\, and\, A_2\, depend on the float position, and <math display="inline">C$ is a function of Reynolds number using an equivalent diameter of a circular runway. (See the graph)



In Formula (5), A1, A2 and af depend on the float position. The summarized result is:

$$Q = C' \sqrt{2g \left(\frac{\rho f - \rho}{\rho}\right) Vf}$$
 (6)

This is a basic formula for all conditions.

About Variable Flow Meter

[For the liquid]

Formula (6) is valid as it is. If the flow meter for water is used for kerosine with a different specific gravity, its indications change as follows:

$$QH_2O=C'\sqrt{2g\left(\frac{\rho f-\rho H_2O}{\rho H_2O}\right)Vf}$$

$$Qoil=C'\sqrt{2g\left(\frac{\rho f-\rho oil}{\rho oil}\right)Vf}$$

$$B$$

By dividing A by B;

Qoil = QH₂O
$$\sqrt{\frac{(\rho f - \rho oil) \times \rho H_2O}{\rho oil \times (\rho f - \rho H_2O)}}$$

Accordingly;

The actual flow rate is obtained by the above formula.

[For the gas]

For the gas, its density ρ is ignorably low to that of float ρ f. The formula can be simplified as follows.

$$Q=C'\sqrt{2g\left(\frac{\rho f}{\rho}\right)Vf}$$

Since the density of float ρf and the volume Vf are constant, the formula can be further simplified as follows.

$$Q=C^{\sim}\sqrt{\frac{1}{\rho}}$$
(7)

As mentioned above, if the Reynolds number is close, C" is considered constant in the case of gas, determining the flow rate according to the density of gas ρ .

Since the Reynolds number is also a function $\frac{D u \rho}{\mu}$ of the density viscosity of gas, however, a considerably complicated analysis is required, if C° changes and density viscosity conditions differ greatly. The density of gas changes depending on the pressure and temperature as well as the gas type. If the same flow meter is used to measure under different conditions, accordingly, the following flow rate relations are theoretically established.

First, the gas state equation;

PV = nRT results in;

$$P\frac{1}{\rho} = nRT$$
 $\rho = \frac{P}{nRT}$

The density is inversely proportional to the absolute temperature T and proportional to the absolute pressure P. Combining this with Formula (7), the following formula is established.

Density of gas ρ_1

Pressure Indicated value Q₁ (L/min at 20°C) by the flow meter

Temperature T₁
Density of gas ρ_2

Pressure Actual flow rate Q2 (L/min at 20°C) when measuring

the conditions for P2

Temperature T

$$Q_2 = Q_1 \times \sqrt{\frac{\rho_1 \times P_2 \times (273 + T_1)}{\rho_2 \times P_1 \times (273 + T_2)}}$$

In the case of the P1/P2 gauge pressure;

$$Q_2 = Q_1 \times \sqrt{ \begin{array}{c} \rho_1(0.1 + P_2G) \; (273 + T_1) \\ \hline \rho_2(0.1 + P_1G) \; (273 + T_2) \end{array} }$$

<Absolute pressure = 0.10133 + Gauge pressure(MPa)>

The following shows examples of specific correction formulas.

(Example 1) When the gas type is different

When the flow meter for H_2 is used for He, P_1 , P_2 , T_1 and T_2 are the same. By substituting the above formula, the following formula results.

QHe = QH₂
$$\sqrt{\frac{\rho H_2}{\rho He}}$$
 = QH₂ $\sqrt{\frac{2}{4}}$ ≈ 0.7 QH₂

The actual flow rate becomes lower than the indicated graduation.

(Example 2) When the pressure condition is different

When the flow meter with atmospheric scale (P1G = OPa) for $\ensuremath{N_2}$ is used to conduct measurement of

 N_2 and 0.3MPa (= P_2G), ρ_1 , ρ_2 , T_1 and T_2 are the same, resulting in the following formula.

$$Q_3 = Q_0 \sqrt{\frac{0.1 + 0.3}{0.1 + 0}} \approx 2Q_0$$

The actual flow rate becomes higher than the indicated graduation.

(Example 3) When the temperature condition is different

When the flow meter calibrated on the basis of 20°C is used at 25°C;

$$(T_1 = 20^{\circ}C), (T_2 = 25^{\circ}C)$$

Since ρ_1 , ρ_2 , P_1 and P_2 are the same, the following formula results

Qactual flow rate = Qindicated value
$$\sqrt{\frac{273 + 20}{273 + 25}} \approx 0.99$$
Qindicated value

The actual flow rate becomes lower than the indicated graduation.

The above-mentioned corrections are based on approximation formulas. A flow rate value may be often inconsistent with a theoretical one under actual conditions. Keeping in mind that a theory may differ from the reality, use the correction formulas.

Unit of flow rate

Generally, the flow meters use the indication of 20°C and 1atm (std, stp, etc.) standard condition or 0°C and 1atm (normal, nor. ntp, etc.) normal condition in many cases. We have defined as follows. As a

rule, the flow rate indication in the catalog of our flow meters refers to the standard condition.

Designation	Unit temperature of flow rate	Unit pressure of flow rate	Suffix	Example of indication
Standard condition	20°C	1atm (Atmospheric pressure)	(stp)	L/min(stp) mL/min(stp)
Normal condition	0°C	1atm (Atmospheric pressure)	(ntp)	L/min(ntp) mL/min(ntp)

Calibration fluid

Our flow meters have 7 types of applicable standard gases; Air, N_2 , O_2 , He, H₂, Ar and CO_2 . These actual gases are used to calibrate the scale of the flow meters according to the condition. For other special gases, they are arranged by us or the customer to perform actual calibration or conversion scale calibration is performed with the Air, N_2 , etc., using the correction formula in Example 1 on Page 53. In the case of the gas with similar mass and properties, the conversion scale calibration method has hardly problems. Compared with the actual gas scale calibration method, however, there may be bigger errors.


Also, in the cases of the special gases, special materials may be required to use, or crystals, etc. may adhere, disabling measurement. For other gases than standard ones, be sure to consult our sales office beforehand. The flow meters for liquid are, as a rule, calibrated with water (H_2O) .

Calibration pressure (for the gases)

As shown in Fig. A, the flow meter is generally used with its outlet opened to the atmosphere or freed from load application (no pressure loss resistance). Such a flow meter is called an "atmospheric pressure scale."

In actual use, however, load pressure resistance is often applied as shown in Fig. B. If it is applied, an indication deviates from an actual flow rate as described in Example 2 on Page 53. There is a method to calculate by this formula to obtain a guide, but there is a gap between a theory and reality, causing an error. This is the case for both pressurization and vacuum pressure.

In such a case, if the pressure applied to the flow meter is known, the scale can be calibrated beforehand in this pressure state. As an example, attach a flow control valve to the outlet of the flow meter as shown in Fig. C and control the pressure applied to the flow meter with a pressure regulating valve to always keep constant pressure application. Then, calibrate the scale under this pressure condition. Such a flow meter scale is called a "load pressure scale."



■ Calibration temperature (for the gases)


As described in Example 3 on Page 53, the density of gas changes depending on the temperature, causing an indication error against the flow meter's graduation. Our flow meters are, as a rule, manufactured at the calibration temperature of 20°C. When there may occur an

indication error because of a difference between the calibration temperature and the actual working temperature, carry out a correction calculation as a guide with the correction formula shown in Example 3 on Page 53.

About Variable Flow Meter

Notation of the flow rate, calibration pressure and temperature unit on the tapered tube

	Manufacturing condition	Indication on tapered tube
Example of gas	Fluid Air Unit of flow rate Standard condition mL/min Calibration pressure OMPa(G)(atm) Calibration temperature 20°C	AIR mL/min(stp) 0MPa 20°C
example of gas	Fluid N ₂ Unit of flow rate Normal condition L/min Calibration pressure 0.2MPa(G)(Load pressure) Calibration temperature 20°C	N ₂ L/min(ntp) 0.2MPa 20°C
Example of liquid	Fluid H ₂ O Unit of flow rate mL/min Calibration temperature 20°C	H₂O mL/min at 20°C



Accuracy


The accuracy of the flow meter is indicated with a percent value of an error against the full-scale flow rate (maximum flow rate measurable with that flow meter). In the case of the RK1400 with 100mL/min, for example, the error is ±2 mL/min because the accuracy is ±2% of

the full scale. Calibration points are specified for each flow rate range. The accuracy is a value at these points. Other points than calibration points are equally distributed. They are also within the accuracy in most cases, but excluded from the warranty.

Scale notation on the tapered tube

Total length	Flow rate range (example: mL/min)	Scale interval (mL/min)	Indicated numerals (example: mL/min)
	0.1 to 1 (10 to 100)	1/20 (5)	10, 50, 100
L = 80	0.2 to 2 (20 to 200)	1/20 (10)	20, 100, 200
L = 00	0.3 to 3 (30 to 300)	1/12 (25) 1/15 only between 0.3 and 0.5 (20 only between 3)	and 50) 30, 50, 100, 150, 200, 250, 300
	0.5 to 5 (50 to 500)	1/20 (25)	50, 100, 200, 300, 400, 500
	0.1 to 1 (10 to 100)	1/20 (5)	10, 20, 30, 40, 50, 60, 70, 80, 90, 100
L = 100	0.2 to 2 (20 to 200)	1/20 (10)	20, 40, 60, 80, 100, 120, 140, 160, 180, 200
L = 100	0.3 to 3 (30 to 300)	1/30 (10)	30, 50, 100, 150, 200, 250, 300
	0.5 to 5 (50 to 500)	1/25 (20) 1/50 only between 0.5 and 0.6 (10 only between 5)) and its above) 50, 100, 200, 300, 400, 500
	0.1 to 1 (10 to 100)	1/20 (5)	10, 20, 30, 40, 50, 60, 70, 80, 90, 100
L = 120	0.2 to 2 (20 to 200)	1/20 (10)	20, 40, 60, 80, 100, 120, 140, 160, 180, 200
L = 120	0.3 to 3 (30 to 300)	1/30 (10)	30, 50, 100, 150, 200, 250, 300
	0.5 to 5 (50 to 500)	1/25 (20) 1/50 only between 0.5 and 0.6 (10 only between 5)) and its above) 50, 100, 200, 300, 400, 500
	0.1 to 1 (10 to 100)	1/40 (2.5)	10, 20, 30, 40, 50, 60, 70, 80, 90, 100
L = 150	0.2 to 2 (20 to 200)	1/40 (5)	20, 40, 60, 80, 100, 120, 140, 160, 180, 200
L = 100	0.3 to 3 (30 to 300)	1/30 (10)	30, 50, 100, 150, 200, 250, 300
	0.5 to 5 (50 to 500)	1/50 (10)	50, 100, 150, 200, 250, 300, 350, 400, 450, 500
	0.1 to 1 (10 to 100)	1/50 (2)	10, 20, 30, 40, 50, 60, 70, 80, 90, 100
L = 200	0.2 to 2 (20 to 200)	1/80 (2.5)	20, 40, 60, 80, 100, 120, 140, 160, 180, 200
L = 200	0.3 to 3 (30 to 300)	1/60 (5)	30, 50, 100, 150, 200, 250, 300
	0.5 to 5 (50 to 500)	1/50 (10)	50, 100, 150, 200, 250, 300, 350, 400, 450, 500
	0.1 to 1 (10 to 100)	1/100 (1)	10, 20, 30, 40, 50, 60, 70, 80, 90, 100
L = 250	0.2 to 2 (20 to 200)	1/100 (2)	20, 40, 60, 80, 100, 120, 140, 160, 180, 200
L = 250	0.3 to 3 (30 to 300)	1/60 (5)	30, 50, 100, 150, 200, 250, 300
	0.5 to 5 (50 to 500)	1/100 (5)	50, 100, 150, 200, 250, 300, 350, 400, 450, 500

Special scales



Shape of the tapered tube

The inside of our glass tapered tubes is not a simple cylinder, but features special molded shapes called the tri flat and rib guide types.

The tri flat type is used for a very low flow rate range below the maximum air flow rate of 5mL/min to 500mL/min, and the rib guide type is used for the maximum flow rate range of 1L/min to 50L/min, allowing stable flow rate measurement.





Tri flat type

Rib guide type

Flow meter with valve

KOFLOC is a general manufacturer of precision flow rate measurement and precision flow rate control. With a combination of these two technologies, we manufacture various flow meters with valve. Flow rate control is almost always accompanied by flow rate measurement. There is a merit of easy specification change in separately assembling the valve and the flow meter, and combining them, but the flow meter with valve has more merits such as saving time and labor for piping, securing the space and allowing general coordination.

In response to these needs, **KOFLOC** manufacture many flow meters with valve. Those with valve include different types such as the simple type, precision type, large flow rate type and bellows type, plus the inlet- and outlet-side installation types.

Upper and lower valves


The upper side of the flow meter is outlet and the lower side is inlet. The following figure illustrates the flow sheet of the upper and lower valves. The pressure loss of the flow meter is quite small and not a big deal for the flow meter alone. When it comes to the flow meter with valve, however, what counts is the inlet and outlet pressures. By attaching the valve, pressure loss will result, causing a difference between the inlet and outlet pressures.


As described in Example 2 on Page 53, the flow meter indicates a different value, depending on the applied pressure. When the valve is attached, note particularly how the pressure applied to the flow meter is affected.

For the lower valve, the inlet pressure P_1 is throttled by a needle, resulting in P_2 at the outlet. This P_2 is the pressure applied to the flow meter. In case there is no significant load resistance on the outlet side (similar to being opened to the atmosphere), P_2 is assumed to be

OMPa(G). Accordingly, calibrate with the atmospheric scale, considering that the pressure applied to the flow meter is zero. Since the valve requires the working pressure condition, however, it is necessary to specify P_1 and P_2 at ordering time. When there is load resistance (P_2 pressure), of course, specify P_2 as well.

For the upper valve, the inlet pressure P_1 is applied to the flow meter. P_1 and P_2 are necessary to select the valve as mentioned above, and the scale of the flow meter needs to be the load pressure scale for P_1 . Accordingly, this flow meter is generally used with the pressure regulating valve so that P_1 will not fluctuate. Particularly, in case there is vacuum decompression from outlet side, an indication error may occur in most cases unless the upper valve type is selected





Selection of the specifications for liquid flow meters

When the fluid is a liquid, note that air bubbles may adhere to the float, failing to obtain precise measurement accuracy. It is recommended to select the upper valve type, because the dissolved air comes out when releasing the pressure of outlet side of the valve.

Also, from the viewpoints of foreign substances and corrosion, when accurate flow rate measurement is required, it is recommended to select the stainless steel as the block material of the flow meter.

About Variable Flow Meter

Principle of the flow meters with reed switch

[About the reed switch]

As shown in the **right figure**, the reed switch has a pair of magnetic reeds enclosed in a glass tube with a certain contact gap together with an inactive gas.

By applying a magnetic field to the reed switch from the external, the reeds are magnetized and sucked to each other into contact, closing a circuit.

Once the magnetic field is gone, the circuit is opened by the elasticity of the reeds.


[Operation with our flow meters]


The **right figure** shows the polarity of a magnet in the float and that in the reed switch.

In case the upper side of the magnet incorporated in the float is set to Polarity S, if the float moves up, the magnetic field increases strength at Polarity N of the magnet in the float and Polarity S of the bias magnet incorporated in the reed switch, turning on the switch. If the float moves down to the contrary, Polarity S of the magnet in the float and that of the bias magnet repel each other, weakening the strength of the magnetic field of the reed switch and turning it off. Thus, the reed switch operates differently depending on the polarity of the magnet incorporated in the float.

The sensitivity (operating state) of the reed switch is greatly susceptible to the distance between the magnet in the float and the bias magnet (Xa), and that between the bias magnet and the reed switch (Xb).

Structure of the reed switch





* How to use

Fix the reed switch at the flow rate graduation desired to be detected. There are Contact A which is turned on if the float moves higher than a set point, and Contact B which is turned on if it moves lower than the set point. Once the contact is turned on, a signal continues to be held unless the float moves in the other direction (self-holding switch).


Principle of the flow meters with photosensor

[About the transmissive photosensor]


This photosensor has a pair of projector and light receiver facing each other so that the light emitted from the projector hits the light receiver.

It detects an object between the projector and the light receiver when the light from the projector is blocked by the detected object.

Light-on diagram



The light enters the light receiver to turn on an operation indication lamp (green / red).



The light is blocked by the float and not received, turning on only a stability indication lamp (green).

[Operation with our flow meters]

Light-on

When the light emitted from the projector enters the light receiver, the operation indication lamp is turned on. (Our standard mode)

Dark-on:

When the light emitted from the projector does not enter the light receiver (blocked by an object), the operation indication lamp is turned on.

Operation indication lamp (green / red):

Turned on if the light enters the light receiver.

(The upper half of the indication lamp is lit up in green and the lower half in red.) $% \begin{center} \end{center} \begin{center} \begin{c$

Stability indication lamp (green):

State that the light is blocked by the float and not received. When the lamp is turned on, there is no problem in use. When it is turned off, there may be a misaligned optical axis, contamination, etc. Or, the power is not connected.


* How to use

Fix the photosensor body at the flow rate graduation desired to be detected. Run a fluid and confirm that the float detects at the sensor position. Adjust the sensitivity with a control knob as required. Different from the reed switch, the photosensor has only a fixed contact.

Precautions for handling the flow meter


- Select a low-humidity place and install the flow meter vertically.
- To pipe the flow meter, select an appropriate material and diameter, depending on the fluid, flow rate and pressure.
- Fully clean inside the piping.
- To read the float, see the figure below.

Float reading position



- * This figure is intended for showing a scale reading position and does not stipulate the shape and structure of a moving part.
- When measuring a flow rate, use at 70% or less of the proof pressure in order to prevent damage on the tapered tube. For the temperature as well, use at 60°C or less in order to prevent damage on the tapered tube and other parts. The tapered tube may be broken due to an abrupt temperature change or a heat shock by the recurring cycles. Avoid applying such a load. Never use any harmful gas or liquid other than the fluids indicated on the tapered tube or at the temperature or pressure beyond the maximum limit. Otherwise, the human body may be hurt.
- If the pressure or flow rate changes abruptly, the float may jump up, breaking the tapered tube. If piped in series with a solenoid valve as illustrated, a considerable amount of fluid runs abruptly even at low pressure. Take care not to directly apply a pressure change by installing a regulator.

Bad example of use




- Our flow meters have quite a narrow gap between the tapered tube and the float for measuring a very low flow rate. If dust, moisture, etc. are allowed in the flow meter, gap is clogged or it becomes unstable. A filter may be attached to the end of the tapered tube, but use a clean and dry gas, allowing in no dust.
- A needle valve is intended to "control flow rate." It does not assure complete shutoff. When stopping a flow of fluid, you are requested to additionally install a stop valve. Note that if the needle valve is turned more than necessary, the product may be damaged.
- When mounting the flow meter to the panel surface, use accessory nuts as illustrated. See the dimension drawing for the panel cutting dimensions.

Mounting to the panel surface <Single-nut mounting>



 When embedding into the panel, use tapped holes in the front of the body as illustrated.

Embedding into the panel



- Tighten nuts and screws with a minimum required force.
- When mounting to the panel or connecting and disconnecting a
 joint, fix a flow meter joint with a spanner and do work in order to
 prevent loosening. After mounting, be sure to conduct leak test
 with soap water, etc.

Flow Meter with Precision Needle Valve

MODEL RK1200 SERIES





Applicable fluids Q_2 Q_3 Q_4 Q_5 Q_5 Q_6 Q_7 Q_8 Q_8

Liquid H₂O

Max. flow rate Gas 5mL/min to 100L/min

Liquid 5mL/min to 2L/min


Accuracy ±2%F.S.

- Available for a wide range of flow rate from minute flow
- High-accuracy measurement of ±2% F.S. or better
- Superior control performance by non-rotating precision needle valve
- Upper needle valve type available
- Wide variations suitable for various conditions of use




RK1200 (valve at top)

Dimensions




- * The figure is for the lower valve. The dimensions are upside
- down for the upper valve. * Dimensions in () are for Air-50L/min and $H_{2}\text{O-}2\text{L/min}$
- Α 80 110 160 210 В 86 116 166 216 C 120 150 200 250 D 130 180 230 100 E 29(36) 29(36) 31(36) 31(36)



Embedding into the panel Mounting to the panel surface (Screw the front acryl cover together) (Mount with accessory nuts

Example of use



Standard Specifications

MODEL	RK1:	200				
Applicable fluids	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.	H ₂ O				
Max. flow rate (Air atm condition for gas)	5mL/min to 100L/min (See the Capacity Table below)	5mL/min to 2L/min (See the Capacity Table below)				
Effective scale	10:1					
Accuracy	±2%	F.S.				
	100mL/min or less: 1MPa(G)	5mL/min or less: 1MPa(G)				
Proof pressure	5L/min or less: 0.7MPa(G)	150mL/min or less: 0.7MPa(G)				
	10L/min or more: 0.5MPa(G)	200mL/min or more: 0.5MPa(G)				
Max. working temperature	60°C					
	SS: SUS316, Hard glass, F	FKM, PCTFE, (PTFE)				
Materials of parts in contact with fluid	B: Brass, Hard glass, NB	R, POM, SUS316, (PTFE)				
Connection	Rc1/4					
Weight	Approx. 450g					

^{*} Of the materials of parts in contact wth fluid, what is in () depends on the manufacturing specification condition.

Capacity Table


Air (atmospheric pressure)

Max. flow rate	5 ml /min	10 ml /min	20 ml/min	30 ml /min	50 mL/min	100 ml /min	150	200 ml /min	300 ml /min	500 ml/min	1 L/min	2 L/min	3 L/min	5 L/min	10 L/min	15 L/min	20 L/min	30 L/min	50 L/min	100 L/min
Total leligiti	1112/111111		1112/111111	1112/11111			1112/111111	1112/111111		1112/11111	L/ //////	L) IIIIII	L/111111	D	O	L/111111	L/111111	D	L/111111	L/ IIIIII
120mm	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	_
150mm	_	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
200mm	-	-	-	_	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	-
250mm	_	_	-	_	_	0	0	0	0	0	0	0	0	0	0	0	0	0	0	_

H₂O

Max. flow rate Total length	5 mL/min	10 mL/min	20 mL/min	30 mL/min	50 mL/min	100 mL/min	150 mL/min	200 mL/min	300 mL/min	500 mL/min	1 L/min	2 L/min
120mm	0	0	0	0	0	0	0	0	0	0	0	
150mm	0	0	0	0	0	0	0	0	0	0	0	0
200mm	0	0	0	0	0	0	0	0	0	0	0	_
250mm	0	0	0	0	0	0	0	0	0	0	0	_

Ordering




^{*} Possible to manufacture with a scale of 0.5mL/min to 3mL/min (air at atmospheric pressure) only for total length of 120mm.
* No shutting O-ring for FFKM option.


High-precision Flow Meter

DDEL RK1400 SERIES Gas N₂, Air, H₂, He, Ar, O₂, CO₂, etc. Liquid H₂O Applicable fluids Gas 5mL/min to 100L/min Liquid 5mL/min to 2L/min Max. flow rate ±2% F.S. Accuracy Available for a wide range of flow rate from minute flow ■ High-accuracy measurement of ±2% F.S. or better ■ Wide variations suitable for various conditions of use

Dimensions



Example of use



Standard Specifications

MODEL	RK1	400			
Applicable fluids	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.	H ₂ O			
Max. flow rate (Air atm condition for gas)	5mL/min to 100L/min (See the Capacity Table below)	5mL/min to 2L/min (See the Capacity Table below)			
Effective scale	10	:1			
Accuracy	±2%	F.S.			
	100mL/min or less: 1MPa(G)	5mL/min or less: 1MPa(G)			
Proof pressure	5L/min or less: 0.7MPa(G)	150mL/min or less: 0.7MPa(G)			
	10L/min or more: 0.5MPa(G)	200mL/min or more: 0.5MPa(G)			
Max. working temperature	60'	°C			
Materials of parts in contact with fluid	SS: SUS316, Hard glass,	FKM, (PTFE, PCTFE)			
Materials of parts in contact with huld	B: Brass, Hard glass, NB	R, SUS316, (PTFE, POM)			
Connection	Rc1/4				
Weight	Approx. 400g				

^{*} Of the materials of parts in contact with fluid, what is in () depends on the manufacturing specification condition.

Capacity Table


Air (atmospheric pressure)

Max. flow rate	0	10 ml /min	20 ml/min	30 ml /min	50 mL/min	100 ml /min	150	200 ml /min	300 ml /min	500 ml/min	1 L/min	2 L/min	3 L/min	5 L/min	10 L/min	15 L/min	20 L/min	30 L/min	50 L/min	100 L/min
Total longar	1112/11111			1112/11111				1112/11111			L)	2,,,,,,,,	27111111			2,,,,,,,,	L/111111	2,,,,,,,,	L/111111	L/111111
120mm	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
150mm	_	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
200mm	-	-	-	_	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	-
250mm	-	_	_	_	_	0	0	0	0	0	0	0	0	0	0	0	0	0	0	_

H₂O

Max. flow rate Total length	0	10 mL/min	20 mL/min	30 mL/min	50 mL/min	100 mL/min	150 mL/min	200 mL/min	300 mL/min	500 mL/min	1 L/min	2 L/min
120mm	0	0	0	0	0	0	0	0	0	0	0	-
150mm	0	0	0	0	0	0	0	0	0	0	0	0
200mm	0	0	0	0	0	0	0	0	0	0	0	
250mm	0	0	0	0	0	0	0	0	0	0	0	_

Ordering



^{*} Possible to manufacture with a scale of 0.5mL/min to 3mL/min (air at atmospheric pressure) only for total length of 120mm.

Purge Flow Meter with Needle Valve

MODEL RK1600R SERIES



Applicable fluids O Gas O N₂, Air, H₂, He, Ar, O₂, CO₂, etc.


Max. flow rate Gas 1 to 20L/min


Accuracy ±5% F.S.


Compact design



Dimensions








Dimensions	by ler	igth cod	е	
Part Code	08	10	12	15
А	48	68	88	118
В	74	94	114	144
С	80	100	120	150
D	61	81	101	131
Е	44	64	84	114

Standard Specifications

MODEL	RK1600R	
Applicable fluids	N ₂ , A/r, H ₂ , He, Ar, O ₂ , CO ₂ , etc.	
Max. flow rate (Air atm condition)	1, 2, 3, 5, 10, 15, 20L/min	
Effective scale	10:1	
Accuracy	±5%F.S.	
Droof propouro	5L/min or less: 0.7MPa(G)	
Proof pressure	10L/min or more: 0.5MPa(G)	
Max. working temperature	60°C	
Materials of parts in contact with fluid	S: SUS304, Hard glass, FKM, PCTFE, SUS316, SUS303, (PTFE)	
Materials of parts in contact with fluid	B: Brass, Hard glass, NBR, POM, SUS316, SUS303, (PTFE)	
Connection	Rc1/8	
Weight	Approx. 250g	

^{*} Of the materials of parts in contact with fluid, what is in () depends on the manufacturing specification condition.


Ordering




^{*} The needle valve is for flow control, so in order to stop the flow, install a stop valve additionally. If the needle valve is turned more than necessary, the product may be damaged.

^{*} In the case of 2L/min or less, flow rate control may become unstable depending on the pressure condition.

Purge Flow Meter



Dimensions




Standard Specifications

MODEL	RK1000	
Applicable fluids	N2, Air, H2, He, Ar, O2, CO2, etc.	
	100, 150, 200, 300, 500mL/min	
Max. flow rate (Air atm condition)	1, 2, 3, 5, 10, 15, 20L/min	
Effective scale	10:1	
Accuracy	±5%F.S.	
Don't assessment	5L/min or less: 0.7MPa(G)	
Proof pressure	10L/min or more: 0.5MPa(G)	
Max. working temperature	60°C	
And the state of t	S: SUS304, Hard glass, FKM, SUS316, (PTFE)	
Materials of parts in contact with fluid	B: Brass, Hard glass, NBR, SUS316, (PTFE)	
Onemarkian	Standard: Rc1/8	
Connection	Option: Rc1/8 with mounting nuts	
Weight	Approx. 200g	

^{*} Of the materials of parts in contact with fluid, what is in () depends on the manufacturing specification condition.


Ordering



Resin Flow Meter








Standard Specifications

MODEL	RK2	OT .					
Applicable fluids	Air / N ₂	WATER					
	0.05 to 0.5L/min, 0.15 to 1L/min,	2.5 to 25mL/min, 30 to 300mL/min,					
Flow rate range (atm condition for gas)	0.5 to 5L/min, 1 to 10L/min, 2.5 to 25L/min,	100 to 800mL/min, 200 to 1600mL/min,					
	5 to 50L/min, 20 to 100L/min	500 to 2800mL/min					
Accuracy	±6%	F.S.					
Proof pressure	0.7MF	Pa(G)					
Max. working temperature	65°	C					
Materials of parts in contact with fluid	ABS, Acryl, SUS303, FKM, POM,	(Hard glass, SUS316, SUS304)					
Connection	Rc1	/4					
Weight	Approx. 150g						

Ordering




^{*} This product is excluded from our scope of repair.

Resin Flow Meter for Large flow rate



Dimensions




Standard Specifications

MODEL	RK50T			
Applicable fluids	Air / N ₂ WATER			
Flow rate range (atm condition for gas)	10 to 100L/min, 20 to 200L/min, 30 to 300L/min 0.3 to 3L/min, 0.5 to 5L/min, 1 to 10L			
Accuracy	±5%F.S.			
Proof pressure	1MPa(G) 3MPa(G)			
Max. working temperature	55°C			
Materials of parts in contact with fluid	Acryl, FKM, SUS303, SUS304, SUS316, (Glass fiber contained nylon)			
Connection	Rc3/8			
Weight	Approx. 350g			

^{*} Of the materials of parts in contact wth fluid, what is in () depends on the manufacturing specification condition.

Ordering




^{*} This product is excluded from our scope of repair.

Resin Flow Meter with Reed Switch

Applicable fluids Gas Air / N2 Liquid WATER Max. flow rate Gas 10 to 100L/min Liquid 250 to 2800mL/min Accuracy ±6%F.S.

Dimensions




Standard Specifications

MODEL	RK20T-RSW						
Applicable fluids	Air / N ₂			WATER			
	Flour rate range	Alarm se	Alarm setting range		Alarm setting range		
	Flow rate range	Contact A	Contact B	Flow rate range	Contact A	Contact B	
Flow rate range	4 to 10L/min	6 to 9.5L/min	4.5 to 8.5L/min	_	_	-	
(atm condition for gas)	2.5 to 25L/min	8 to 20L/min	5 to 16L/min	20 to 250mL/min	50 to 250mL/min	30 to 230mL/min	
	5 to 50L/min	16 to 46L/min	10 to 36L/min	100 to 1500mL/min	300 to 1500mL/min	150 to 1400mL/min	
	20 to 100L/min	45 to 100L/min	35 to 90L/min	600 to 2800mL/min	900 to 2800mL/min	700 to 2800mL/min	
Accuracy	±6%F.S.						
Proof pressure	0.7MPa(G)						
Working ambient temperature	10°C to 35°C (no dew condensation)						
Materials of parts in contact with fluid	ABS, Acryl, SUS303, FKM, POM, SUS316, (Ferrite magnet, epoxy-coated magnet)						
Connection	Rc1/4						
Contact capacity	DC30V DC10W DC0.5A						
Cable length	65cm						
Weight	Approx. 200g						


^{*} Of the materials of parts in contact wth fluid, what is in () depends on the manufacturing specification condition.

Ordering




^{*} This product is excluded from our scope of repair.


Flow Meter for Cylinder Regulator



Dimensions



Example of use




Standard Specifications

MODEL	RK4400		
Applicable fluids	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.		
Max. flow rate (Air atm condition)	10, 50, 100, 500mL/min		
	1, 5, 10, 15, 20L/min		
Effective scale	10:1		
Accuracy	±2%F.S.		
Proof pressure	0.3MPa(G)		
Max. working temperature	40°C		
	SS: SUS316, Hard glass, FKM, PCTFE, (PTFE)		
Materials of parts in contact with fluid	B: Brass, Hard glass, NBR, POM, PCTFE, SUS316, (PTFE)		
Connection	Inlet: PF1/4		
Connection	Outlet: Rc1/4 + Ø7 hose nipple		
Weight	Approx. 370g		

 $^{^{\}star}$ Of the materials of parts in contact with fluid, what is in () depends on the manufacturing specification condition.

Ordering



Liquid 1 to 5L/min

Flow Meter with Reed Switch

MODEL RK1970 / RK1975 / RK1976 SERIES





Max. flow rate Gas 30 to 150L/min


Accuracy ±5% F.S.


- Alarm function by reed switch
- Upper needle valve type available



RK1975-VD

Dimensions





Dimensions by length code

	, ,	
Part Code	15	20
Α	36	36
В	35	35
L1	150	200
L2	130	180
F	110	160
G	116	166
Н	100	150

^{*} H exists when the reed switch is included.


Standard Specifications

MODEL	RK1970, RK1975, RK1976			
Applicable fluids	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc. (RK1975 and RK1976 not available for H ₂)	H ₂ O		
Max. flow rate (Air atm condition for gas)	Total length 150mm: 30, 100, 150L/min Total length 200mm: 100, 150L/min	Total length 150mm: 1, 3, 5L/min Total length 200mm: 3, 5L/min		
Effective scale	10:1			
Accuracy	±5%F.S.			
Proof pressure	0.5MPa(G)			
Working ambient temperature	10°C to 35°C (no dew condensation)			
Materials of parts in contact with fluid	SUS316, Hard glass, FKM, POM, (PTFE, nylon)			
Connection	Rc1/4			
Alarm setting range	RK1975, RK1976: 20 to 90%F.S.			
Contact capacity	RK1975, RK1976: 100VAC / 100VDC, AC10VA / DC10W			
Cable length	RK1975, RK1976: 65cm			
Weight	Approx. 600g			


 $^{^{\}star}$ Of the materials of parts in contact with fluid, what is in () depends on the manufacturing specification condition.

Ordering

<with needle valve type>




<without needle valve type>



Flow Meter for Large flow rate


MODEL RK2000 / RK2005 / RK2006 SERIES Applicable fluids Gas N₂, Air, H₂, He, Ar, O₂, CO₂, etc. Liquid H₂O Max. flow rate Gas 100 to 1000L/min Liquid 10 to 30L/min Accuracy ±5%F.S. Available for large flow rate Upper needle valve type available Alarm function by reed switch

Dimensions



* Dimensions in () are for SUS material.

(Cutting dimensions)




RK2000-0


RK2006-VU

 * The RK2005 and RK2006 can only be embedded into the panel.

<<400 to 1000L/min>>



(Cutting dimensions)



* The RK2005 and RK2006 can only be embedded into the panel.


Standard Specifications

MODEL	RK2000, RK2005, RK2006			
Applicable fluids	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc. (RK2005 and RK2006 not available for H ₂)	H ₂ O		
Max. flow rate (Air atm condition for gas)	Total length 200mm: 100, 200, 250, 300L/min Total length 250mm: 400, 500, 700, 1000L/min	Total length 200mm: 10L/min Total length 250mm: 20, 30L/min		
Effective scale	10:1			
Accuracy	±5%F.S.			
Proof pressure	0.7MPa(G)			
Max. working temperature	RK2000: 60°C			
Working ambient temperature	RK2005, RK2006: 10°C to 35°C (no dew condensation)			
Materials of parts in contact with fluid	S: SUS304, Hard glass, FKM, (SUS316, PCTFE, PTFE) B: Brass, Hard glass, SUS304, NBR, (SUS316, POM, PTFE)			
Connection	Total length 200mm: Rc3/8 Total length 250mm: Rc3/4			
Alarm setting range	RK2005, RK2006: 20 to 90%F.S.			
Contact capacity	RK2005, RK2006: AC100V / DC100V, AC10VA / DC10W			
Cable length	RK2005, RK2006: 65cm			
Weight	Approx. 1,000g			


 $^{^{\}star}$ Of the materials of parts in contact wth fluid, what is in () depends on the manufacturing specification condition.

Ordering

<with needle valve type>



<without needle valve type>



^{*} Even in case the maximum gas flow rate exceeds 400L/min, total length could be 200mm depending on the condition.

Flow Meter with Photosensor

MODEL RK1812 / RK1814 SERIES





Gas N₂, Air, H₂, He, Ar, O₂, CO₂, etc. Liquid H₂O Applicable fluids

Gas 50mL/min to 50L/min Max. flow rate

Liquid 20mL/min to 1L/min

±2% F.S. Accuracy


- Alarm function by photosensor
- High-accuracy measurement of ±2% F.S. or better
- Superior control performance by non-rotating precision needle valve
- Upper needle valve type available



RK1812 (valve at bottom)

RK1814

Dimensions









Part Code	12	15	20	25
Α	120	150	200	250
R	100	130	180	230

Part	12	15	20	25	
Α	120	150	200	250	
В	100	130	180	230	
С	80	110	160	210	
D	86	116	166	216	
Е	70	100	150	200	
F	29	29	31	31	
G	Bc1/4				





(Cutting dimensions)




Standard Specifications

MODEL		RK1812,	RK1814		
Applicable fluids	N2, Air,	H ₂ , He, Ar, O ₂ , CO ₂ , etc	H ₂ O		
Max. flow rate	50	mL/min to 50L/min	20mL/min to 1L/min		
(Air atm condition for gas)	(See the Capacit	ty Table of RK1200 and RK1400)	(See the Capacity Table of RK1200 and RK1400)		
Effective scale		10:1 ±2%F.S.			
Accuracy					
	100ml	/min or less: 1MPa(G) 20mL/min or less: 1MPa(G			
Proof pressure	5L/min or less: 0.7MPa(G)		150mL/min or less: 0.7MPa(G)		
	10L/min or more: 0.5MPa(G)		200mL/min or more: 0.5MPa(G)		
Working ambient temperature		5 to	55°C		
	DI(4.04.0	SS: SUS316, Hard gl	ass, FKM, PCTFE, (PTFE)		
Managed and a second for a second sec	RK1812	B: Brass, Hard glas	s, NBR, POM, SUS316, (PTFE)		
Materials of parts in contact with fluid	DIVIO I	SS: SUS316, Hard glass, FKM, (PTFE)			
	RK1814	B: Brass, Hard glas	s, NBR, SUS316, (PTFE)		
Connection		Rc1/4			
Alarm setting range		10 to 9	10%F.S.		
Weight		Approx	c. 450g		

^{*} Of the materials of parts in contact with fluid, what is in () depends on the manufacturing specification condition.

Photosensor Specifications


Operating power	24VDC±10%
Power consumption	Projector: 15mA or less Light receiver: 22mA or less
Output mode	NPN open collector, Sink current: Max. 80mA (30VDC)
Operation mode	Light-on
Response time	0.5msec or less
Cord	Projector: 0.15mm² x 2 cores (2m) Light receiver: 0.15mm² x 3 cores (2m)
Protective structure	IP64
Manufacturer	Takenaka Electronic Industrial Co., Ltd.
	Photoelectric switch incorporating UM-T15TV (24VDC)
Model	Provided with relay control knob (on light receiver side)




^{*}When adjusting the photosensor, loosen the sensor fixing knob first. The transmissive projector is omitted here because it has only power input (brown: 24VDC, blue: 0V). See the photosensor instruction manual enclosed before use.

Ordering

<RK1812: with needle valve type>



<RK1814: without needle valve type>



^{*} If you want multiple sensors to be installed, consult our sales office.

Flow Meter with Bellows Needle Valve

MODEL RK1500 SERIES





Applicable fluids Gas N2, Air, H2, He, Ar, O2, CO2, etc. Liquid H2O


Max. flow rate Gas 5mL/min to 30L/min Liquid 5mL/min to 1L/min

Accuracy ±2%F.S.

- Low leak thanks to bellows sealed needle valve
- Available for minute flow rate as well
- High-accuracy measurement of ±2% F.S. or better
- Superior control performance by non-rotating precision needle valve
- Upper needle valve type available



Dimensions





2-04 MS screw, Prepared hole de


(Cutting dimensions)


Embedding into the panel Mounting to the panel surface (crew the front acryl cover togethar) (Front mounting nut is optional)


Dimensions by length code

Part	Code	12	15	20	25			
	Α	120	150	200	250			
	В	70	100	150	200			
	С	88	118	168	218			
	D	95	125	175	225			
	1/4 SWL	39	39	39	39			
E	1/8 SWL	37	37	37	37			
	1/4 VCR	37	37	37	37			
	F	68	98	148	198			
1	G	29	29	31	31			

Example of use







Standard Specifications

MODEL	RK1	500
Applicable fluids	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.	H ₂ O
Max. flow rate (Air atm condition for gas)	5mL/min to 30L/min (See the Capacity Table below)	5mL/min to 1L/min (See the Capacity Table below)
Effective scale	10:	:1
Accuracy	±2%	F.S.
	100mL/min or less: 1MPa(G)	5mL/min or less: 1MPa(G)
Proof pressure	5L/min or less: 0.7MPa(G)	150mL/min or less: 0.7MPa(G)
	10L/min or more: 0.5MPa(G)	200mL/min or more: 0.5MPa(G)
Max. working temperature	60°	°C
Materials of parts in contact with fluid	SUS316, Hard glass,	FKM, PCTFE, (PTFE)
Connection	Standard: 1/4SWL ty	уре
Connection	Option: 1/8SWL ty	/pe, 1/4VCR type
Weight	Approx	. 800g

^{*} Of the materials of parts in contact with fluid, what is in () depends on the manufacturing specification condition.

Capacity Table


Air (atmospheric pressure)

All (atmospheric pi	coourc)																	
Max. flow rate	5	10	20	30	50	100	150	200	300	500	1	2	3	5	10	15	20	30
Total length	mL/min	mL/min	mL/min	mL/min	mL/min	mL/min	mL/min	mL/min	mL/min	mL/min	L/min							
120mm	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
150mm	_	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
200mm	-	_	-	-	0	0	0	0	0	0	0	0	0	0	0	0	0	0
250mm	_	_	_	_	_	0	0	0	0	0	0	0	0	0	0	0	0	0

H₂O

Max. flow rate Total length	0	10 mL/min	20 mL/min	30 mL/min	50 mL/min	100 mL/min	150 mL/min	200 mL/min	300 mL/min	500 mL/min	1 L/min
120mm	0	0	0	0	0	0	0	0	0	0	0
150mm	0	0	0	0	0	0	0	0	0	0	0
200mm	0	0	0	0	0	0	0	0	0	0	0
250mm	0	0	0	0	0	0	0	0	0	0	0

Ordering



^{*} Possible to manufacture with a scale of 0.5mL/min to 3mL/min (air at atmospheric pressure) only for total length of 120mm.
* No shutting O-ring for FFKM option.

^{*} If you need the front panel mounting nut, let us know at ordering time.

^{* &#}x27;SWL type' and 'VCR type' are shortened to SW and VCR in Ordering code.

Low pressure Flow Meter

MODEL RK130 / RK230 / RK260 SERIES







Applicable fluids Gas Air, O₂, LNG, C₃H₈

Max. flow rate Gas 10 to 1000L/min


Accuracy RK130: ±2%F.S. RK230, RK260: ±5%F.S.

- Available for use at low pressure
- Available for large flow rate

RK130




Dimensions



RK230








RK260



Dimensions



Standard Specifications

MODEL	RK130
Accuracy	±2%F.S.
Proof pressure	0.5MPa(G)
Max. working temperature	50°C
Materials of parts	SS: SUS316, Hard glass, FKM, PCTFE
in contact with fluid	B: Brass, Hard glass, NBR, SUS316, PCTFE
Connection	Rc1/4

10L/min	1.6 to 4kPa
20L/min	2.5 to 5kPa
30L/min	5 to 10kPa

* When the pressure is relatively high, the RK1200 is recommended from a viewpoint of flow rate control.


Flow rate range (atmospheric pressure)

	Flow rate ra	Pressure loss			
Air	02	LNG	C ₃ H ₈	(kPa)	Float materia
1 to 10	1 to 10	1 to 10	0.8 to 8	0.6	Hard glass
2 to 20	2 to 20	2 to 20	1.5 to 15	1.4	Hard glass
3 to 30	3 to 30	3 to 30	2.5 to 25	3.5	SUS316

^{*} The pressure loss is the result of measurement with no load applied to the fittings and piping.

Ordering

Ordering



Standard Specifications

MODEL	RK230
Accuracy	±5%F.S.
Proof pressure	0.5MPa(G)
Max. working temperature	50°C
Materials of parts	S: SUS304, Hard glass, SUS316, FKM, PCTFE, PTFE, POM
in contact with fluid	B: Brass, Hard glass, SUS316, NBR, PTFE, SUS304, POM
Connection	Rc3/8

Differential pressure range (Air atmospheric pressure)

30L/min	1.5 to 3kPa
50L/min	2 to 5kPa
100L/min	2.5 to 15kPa

* When the pressure is relatively high for 100L/min, the RK2000 is recommended from a vie

Flow rate range (atmospheric pressure)

SS	Pressure loss	Flow rate range (L/min)							
Float m	(kPa)	C ₃ H ₈	LNG		02		Air		
P0	0.5	2.5 to 25	to 40	4	3 to 30	30	3 to		
	0.7	4 to 40	to 60	8	5 to 50	50	5 to		
(polyaceta	1.5	10 to 80	to 120	20	10 to 90	100	10 to		

 * The pressure loss is the result of measurement with no load applied to the fittings and piping.

MODEL Connection Fluid Outlet pressure Block material Max. flow rate Needle valve RK230 S: SUS304 3/8: Rc3/8 D: at bottom RK230 S 3/8 Air 100L/min 2.5kPa 0kPa D

Standard Specifications

MODEL	RK260
Accuracy	±5%F.S.
Proof pressure	0.5MPa(G)
Max. working temperature	50°C
Materials of parts	S: SUS304, Hard glass, FKM, PTFE, (POM)
in contact with fluid	B: Brass, Hard glass, NBR, PTFE, SUS304, (POM)
Connection	Rc3/4


^{*} Of the materials of parts in contact with fluid, what is in () depends on the manufacturing specification condition

Differential pressure range (Air atmospheric pressure)

100L/min	1.6 to 3.5kPa	500L/min	7 to 40kPa
200L/min	2.2 to 10kPa	800L/min	18 to 50kPa
300L/min	3.6 to 20kPa	1000L/min	30 to 50kPa

Flow rate range (atmospheric pressure)

	Flow rate ra	ange (L/min)		Pressure loss	Float material
Air	02	LNG	C ₃ H ₈	(kPa)	rioat iliateriai
10 to 100	10 to 100	20 to 130	10 to 80	0.6	
20 to 200	20 to 190	25 to 250	20 to 150	1.2	POM
50 to 300	50 to 300	70 to 400	50 to 250	2.6	(polyacetal, white)
100 to 500	100 to 450	150 to 600	80 to 400	5.5	
80 to 800	80 to 750		80 to 600	15	SUS304
100 to 1000	100 to 1000	100 to 1000	80 to 800	23	303304



Flexible Flow Meter

MODEL RK1100 SERIES

Applicable fluids Gas N2, Air, H2, He, Ar, O2, CO2, etc.


Max. flow rate Gas 10mL/min to 20L/min

Accuracy ±2%F.S.


- Possible to disassemble and reassemble
- Capable of selecting a non-rotating precision needle valve
- Upper needle valve type available



Dimensions









Dimensions by length code

Part	Code	12	15	20	25
	Α	120	150	200	250
	В	64	94	144	194
	С	96	126	176	226
D	Rc1/4	14	14	14	14
Е	Rc1/4	M17×1	M17×1	M17×1	M17×1


MODEL	L
RK1100-0	0
RK1100-V	33MAX
RK1100-PV	40

Example of use





Disassembled parts



(1)	Panel mounting nuts
(2)	Gas outlet joint
(3)	Gas inlet joint
(4)	Glass tube retainer
(5)	Upper block
(6)	Backplate base
(7)	Lower block
(8)	Glass tapered tube
(9)	Acryl cover
10)	Needle valve

Standard Specifications

MODEL	RK1100						
Applicable fluids	N ₂ , A r, H ₂ , He, Ar, O ₂ , CO ₂ , etc.						
	0, PV: 10mL/min to 20L/min						
Max. flow rate (Air atm condition)	V: 1 to 20L/min						
	(See the Capacity Table below)						
Effective scale	10:1						
Accuracy	±2%F.S.						
Proof pressure	0.5MPa(G)						
Max. working temperature	60°C						
	S: SUS304, Hard glass, SUS316, FKM, (SUS303, PCTFE, PTFE, nylon)						
Materials of parts in contact with fluid	A: Al, Brass, Hard glass, SUS316, NBR, (SUS303, POM, PTFE, nylon)						
Connection	Rc1/4						
Weight	Approx. 400g						

^{*} Of the materials of parts in contact with fluid, what is in () depends on the manufacturing specification condition.


Capacity Table

Air (atmospheric pressure)


Max. flow rate Total length	10 mL/min	20 mL/min	30 mL/min	50 mL/min	100 mL/min	150 mL/min	200 mL/min	300 mL/min	500 mL/min	1 L/min	2 L/min	3 L/min	5 L/min	10 L/min	15 L/min	20 L/min
120mm	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
150mm	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
200mm	-	1-2	-	0	0	0	0	0	0	0	0	0	0	0	0	0
250mm	_	_	_	_	_	_	0	0	0	0	0	0	0	0	0	0

Ordering





<without needle valve type>



Flow Meter with Stand

MODEL RK1310 SERIES NEW





Applicable fluids M_2 , Air, M_2 , He, Ar, O_2 , CO_2 , etc. Liquid M_2O


Max. flow rate Gas 5mL/min to 100L/min Liquid 5mL/min to 2L/min

Accuracy ±2%F.S.

- With stand
- Available for minute flow rate as well
- High-accuracy measurement of ±2% F.S. or better
- Superior control performance by non-rotating precision needle valve
- Upper needle valve type available




Dimensions






Dimensions by length code Part Code 12 15 20 160 25 210 110 86 116 166 216 120 150 200 250 100 130 29(36) 29(36) 31(36) 31(36)

<< RK1310-0, Air atm, 60 to 100L/min>>








* Dimensions of the stand are common.

Standard Specifications

MODEL	RK1	310		
Applicable fluids	N2, Air, H2, He, Ar, O2, CO2, etc.	H ₂ O		
Max. flow rate	5mL/min to 100L/min	5mL/min to 2L/min		
Air atm condition for gas) (See the Capacity Table of RK1200 and RK1400)		(See the Capacity Table of RK1200 and RK1400)		
Effective scale	10	0:1		
Accuracy	±2%	6F.S.		
	100mL/min or less: 1MPa(G)	5mL/min or less: 1MPa(G)		
Proof pressure	5L/min or less: 0.7MPa(G)	150mL/min or less: 0.7MPa(G)		
	10L/min or more: 0.5MPa(G)	200mL/min or more: 0.5MPa(G)		
Max. working temperature	60	0°C		
Materials of parts in contact	SS: SUS316, Hard glass,	FKM, PCTFE, (PTFE)		
with fluid	B: Brass, Hard glass, NI	BR, POM, SUS316, (PTFE)		
Connection	Rc	1/4		

 $^{^{\}star}$ Of the materials of parts in contact wth fluid, what is in () depends on the manufacturing specification condition.

Ordering




Multiple Flow Meter with Needle Valve

Upper needle valve type available

MODEL RK120X SERIES Applicable fluids Gas N₂, Air, H₂, He, Ar, O₂, CO₂, etc. Max. flow rate Gas 5mL/min to 20L/min Accuracy ±2%F.S. Capable of gas measurement and control up to 4 lines with one unit Stand installable Available for minute flow rate as well High-accuracy measurement of ±2% F.S. or better Superior control performance by non-rotating precision needle valve

Dimensions



MODEL	Α	В				
RK1202	50	120	150	200	250	
RK1203	75	120	150	200	250	
RK1204	100	120	150	200	250	

RK1202

(Valve at bottom, with stand)


	C
B=120	100
B=150	130
B=200	180
B=250	230

Standard Specifications

MODEL	RK1202, RK1203, RK1204					
Applicable fluids	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.					
Max. flow rate (Air atm condition)	5mL/min to 20L/min					
wax. now rate (An atm condition)	(See the Capacity Table of RK1200)					
Effective scale	10:1					
Accuracy	±2%F.S.					
Proof pressure	0.5MPa(G)					
Max. working temperature	60°C					
Materials of parts in contact with fluid	SS: SUS316, Hard glass, FKM, PCTFE, (PTFE, nylon)					
Materials of parts in contact with fluid	B: Brass, Hard glass, SUS316, NBR, POM, (PTFE, nylon)					
Connection	Rc1/4					

^{*} Of the materials of parts in contact with fluid, what is in () depends on the manufacturing specification condition.

Ordering



^{*} For the fluid, Max. flow rate, supply pressure and outlet pressure, specify them in order of ascending flow rate from the left as you face for the number of glass tubes.

Multiple Flow Meter

MODEL RK140X SERIES



Gas N₂, Air, H₂, He, Ar, O₂, CO₂, etc. Applicable fluids


Gas 5mL/min to 20L/min Max. flow rate

±2% F.S. Accuracy

- Capable of gas measurement up to 4 lines with one unit
- Stand installable
- Available for minute flow rate as well
- High-accuracy measurement of ±2% F.S. or better



Dimensions



MODEL	Δ.	pare		D		C	D
MODEL	A			В		U	U
RK1402	50	120	150	200	250	50	44
RK1403	75	120	150	200	250	75	69


	Е	F	G
B = 120	100	74	84
B = 150	130	104	114
B = 200	180	154	164
B = 250	230	204	214

Standard Specifications

MODEL	RK1402, RK1403, RK1404			
Applicable fluids	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc			
Max. flow rate (Air atm condition)	5mL/min to 20L/min			
wax. now rate (Air attil condition)	(See the Capacity Table of RK1400)			
Effective scale	10:1			
Accuracy	±2%F.S.			
Proof pressure	0.5MPa(G)			
Max. working temperature	60°C			
Make delay of the second of the field	SS: SUS316, Hard glass, FKM, (PTFE, nylon)			
Materials of parts in contact with fluid	B: Brass, Hard glass, NBR, SUS316, (PTFE, nylon)			
Connection	Rc1/4			

^{*} Of the materials of parts in contact with fluid, what is in () depends on the manufacturing specification condition.

Ordering



^{*} For the fluid, maximum flow rate and pressure condition, specify them in order of ascending flow rate from the left as you face for the number of glass tubes.

Multiple Flow Meter for Gas Mixing

MODEL RK120XM SERIES Applicable fluids Qas N₂, Air, H₂, He, Ar, O₂, CO₂, etc.


Max. flow rate Gas 50mL/min to 10L/min (Max. 10L/min for 1 line, Max. 20L/min in total)

Accuracy ±2%F.S.

- Capable of simple gas mixing up to 4 lines
- Stand installable
- High-accuracy measurement of ±2% F.S. or better
- Superior control performance by non-rotating precision needle valve



Dimensions




Dimensions of	each part
MODEL	А
1202M	50
1203M	75
1204M	100

Standard Specifications

MODEL	RK1202M, RK1203M, RK1204M			
Applicable fluids	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc			
Max. flow rate (Air atm condition)	50mL/min to 10L/min (Max. 10L/min for 1 line, Max. 20L/min in total)			
wax. now rate (All attil condition)	(See the Capacity Table of RK1200)			
Effective scale	10:1			
Accuracy	±2%F.S.			
Proof pressure	0.5MPa(G)			
Max. working temperature	60°C			
Makadala af asaka la saukak wiki Madal	SS: SUS316, Hard glass, FKM, PCTFE, (PTFE, nylon)			
Materials of parts in contact with fluid	B: Brass, Hard glass, NBR, POM, SUS316, (PTFE, nylon)			
Connection	Rc1/4			

 $^{^{\}star}$ Of the materials of parts in contact with fluid, what is in () depends on the manufacturing specification condition.

Ordering



^{*} For the fluid, maximum flow rate, supply pressure and outlet pressure, specify them in order of ascending flow rate from the left as you face for the number of glass tubes.

Flow Meter for Large flow rate

MODEL RK1950AP SERIES





Applicable fluids Gas Air

Liquid H₂O

Max. flow rate

Gas 80L/min to 25m³/min

Liquid 1.5 to 900L/min

Accuracy ±2%F.S.


Available for large flow rate



Threaded type

Hange type

Dimensions




Bore	d	Α	В
10A	3/8	52	41
15A	1/2	52	41
20A	3/4	62	46
25A	1	73	41*

Bore	L	øD	øС	f	t	n-øh
10A		90	65	1	14	4-15
15A		95	70	1	16	4-15
20A		100	75	1	18	4-15
25A		125	90	1	18	4-19
32A	220	135	100	2	20	4-19
40A		140	105	2	20	4-19
50A		155	120	2	20	4-19
65A		175	140	2	22	4-19
80A		185	150	2	22	8-19
100A	250	210	175	2	24	8-19

Standard Specifications

MODEL	RK1950AP					
Applicable fluids		Air		H ₂ O		
	10A: 80 to 350L/min	15A: 80 to 500L/min	10A: 1.5 to 10L/min	15A: 1.5 to 15L/min		
Max, flow rate	20A: 80 to 1000L/min	25A: 0.4 to 3m ³ /min	20A: 1.5 to 30L/min	25A: 9 to 100L/min		
	32A: 2 to 5m3/min	40A: 2.5 to 6m ³ /min	32A: 60 to 150L/min	40A: 90 to 200L/min		
(Air atm condition for gas)	50A: 2.5 to 9m3/min	65A: 8 to 15m3/min	50A: 80 to 300L/min	65A: 250 to 500L/min		
	80A: 8 to 15m3/min	100A: 12 to 25m3/min	80A: 250 to 500L/min	100A: 400 to 900L/min		
Accuracy	±2%F.S.					
Max. working pressure	40A or less: 1MPa(G)					
Max. Working pressure	50A or more: 0.8MPa(G)					
Max. working temperature	120°C					
Materials of parts in contact with fluid	SUS304, Polysulphone resin (amber, transparent), NBR					
Connection	25A or less: JIS10K RF flange or thread					
Connection		32A or more: JIS10	OK RF flange			

Ordering



^{*} Specifying pressure condition is necessary to check whether the required pressure is satisfied for the desired specifications, prevent hunting, and for calibration.



List of Flow Control Valve























About Flow Control Valve

Types of flow control valves


[1] Needle valves

The needle valve is designed to adjust the opening of a small orifice in the flow path with an acicular or bar-shaped needle to control a flow rate by a resistance change of the flow path, serving as a resistor in a way. Accordingly, the flow rate changes as the pressure applied to the valve changes. To cope with this, a pressure regulator is installed in the front stage as shown in Fig. A to ensure that the constant pressure is applied to the valve, thereby obtaining a constant flow rate.

This method is inexpensive and effective when there is no change in the pressure loss on the valve outlet side (secondary side), and is frequently used.

The needle valves are largely classified into the simple and precision types. The simple type has a needle part integrated with a knob part. When adjusting a flow rate, the needle part moves rotationally to control the flow rate. For the precision type, on the other hand, the needle part is not integrated with the knob part, and the needle part moves irrotationally. The precision type is superior in both easy setting of the flow rate and stability.


Fig. A. Flow rate control by needle valve



[2] Flow controller for fluctuating supply pressure

It is a flow controller that combines the functions of the needle valve in [1] and the pressure regulator. Even if the supply-side pressure changes, the flow rate can be always maintained constantly. (Fig. B)


 $\label{fig:bound} \mbox{Fig. B. Flow rate control by Flow controller for fluctuating supply pressure } \\$



[3] Flow controller for fluctuating outlet pressure

If the pressure loss of outlet side changes, flow rate may also change for the methods of [1] and [2]. In such a case, Flow controller for fluctuating outlet pressure condition is used to control the flow rate in the flow sheet illustrated in Fig. C. With the supply-side pressure controlled by the regulator, the flow controller unsusceptible to outlet-side pressure fluctuations allows flow rate control affected by neither the supply nor outlet pressure.

Fig. C. Flow rate control by Flow controller for fluctuating outlet pressure



[4] Liquid flow controller

As with the flow controller for gas, the flow rate is kept constantly against one-sided pressure fluctuations by a combination of a needle valve and a diaphragm.

[5] Proportional solenoid valve


This valve adjusts the opening by the applied voltage or current, not by manual control like the needle valve, to control the flow rate or pressure. Feedback control is available with flow rate sensor or pressure sensor circuit.

Flow rate characteristics chart and CV value

The flow rate control characteristics of the needle valve are shown by the below-mentioned flow rate characteristics chart. In the example below, (B) denotes a use method which changes the flow rate greatly by slightly turning the valve, making setting difficult and losing stability. Accordingly, it is necessary to select conditions as close to the state of (A) as possible.

KOFLOC manufactures each valve suitable to different working conditions. By specifying a needle number or a fluid name, the supply pressure (primary pressure), outlet pressure (load pressure or secondary pressure) and maximum working flow rate, we manufacture and provide the valve with the best control characteristics.

Flow rate characteristics chart



The following describes the CV value used as a flow rate characteristics for the needle valves. The CV value, a kind of flow coefficient, is a guide to indicate approximate flow rate under a certain pressure condition.

The general formulas are as shown in the table.

P₁: Supply-side absolute pressure [MPa (abs)]


P2: Outlet-side absolute pressure [MPa (abs)]

Q: Flow rate [m³/h]

ρ: Specific gravity (Gas: Air = 1, Liquid: Water = 1)

 $\begin{array}{c|c} P_2 > \frac{P_1}{2} & P_2 \leq \frac{P_1}{2} \\ \hline \text{Non-viscous} & \text{CV} = 0.366Q \; \sqrt{\frac{p}{P_1 - P_2}} \\ \hline Gas_{\text{(at 20°C)}} & \text{CV} = \frac{Q}{4170} \; \sqrt{\frac{p \; (273 + t)}{(P_1 - P_2) \; P_2}} \; \text{CV} = \frac{Q}{2090 P_1} \sqrt{p \; (273 + t)} \\ \hline \end{array}$

With the needle valve, the CV value changes as shown in the figure below, depending on the valve opening. In actual selection of the valve, the Max. CV value in the figure below is important to secure the maximum flow rate.



If this Max. CV value is substituted for the aforementioned formula to obtain Q, the maximum flow rate is derived under the working pressure and temperature conditions. This method, however, becomes less applicable as the flow rate gets more precise, take it only as a guide.

As an example, obtain the flow rate with the valve fully opened when controlling the 20°C air at the supply pressure of 0.1MPa(G) and outlet pressure of 0MPa(G), using the valve of Max. CV 0.075. Assuming the gauge pressure (G) to be the absolute pressure, 0.1MPa(abs) should be added, resulting in the following formula.

$$P_1 = 0.2MPa(abs)$$
 $P_2 = 0.1MPa(abs)$

$$P_2 \le \frac{P_1}{2}$$
 $0.075 = \frac{Q}{2090 \times 0.2} \sqrt{1 \times (273 + 20)}$
* $Q \approx 1.8 [m^3/h] = 30 [L/min]$

Under the above conditions, accordingly, the flow rate of 30L/min will be limited by switching from fully closed to fully opened.

About Flow Control Valve

Examples of flow rate characteristics of needle valves

KOFLOC's needle valves have various needle numbers according to the flow rate.

Precision type needle numbers

Simple type needle numbers

{ N1, N2, N3 (2400)

Bellows type needle numbers

BSS1, BS1, B1, B2, B2A, B3, B3B, B4, B4A, B5, B6, B6A, B7 (2450)

The following graphs summarize the characteristics of typical needle valves for each Model. Use them only as guides because if they are actually used, they may occur certain discrepancies due to inclusion of errors in the working conditions and instrumental errors, and characteristics arrangement at the differential pressure.

For the gases, arrangement is made with the air as the typical one. For other gases, multiply a flow rate value by


and use a resultant value as a guide.


(Example) He flow rate = Air flow rate
$$\times \sqrt{\frac{28.8}{4}}$$


For the liquids, water is assumed to be the typical one. For other liquids, multiply a flow rate value by


In the case of high viscosity, however, inquire our sales because there is a viscosity coefficient.


2412 Examples of flow rate control characteristics (Unit: K = kPa)






















2400/2450 Examples of flow rate control characteristics (Unit: K = kPa)





















2412D Examples of flow rate control characteristics (Unit: K = kPa)










About Flow Control Valve


Principle of the Precision needle valve (2412)

When a needle shaft is roated, its movement is conveyed to an adjusting screw receiver. The adjusting screw receiver takes a rotational force, but blocks a rotary motion by a pin attached to it. Energy by the rotational force moves the adjusting screw receiver back and forth along a pin groove. This moves a needle pin attached to the end of the adjusting screw receiver back and forth. The needle pin moves back and forth through an orifice with a constant hole to

adjust the opening of the orifice, narrowing down a flow rate coming in from the IN side.

Model 2412 has very high adjustability among general needle valves. Capable of selecting 15 types of ranges, it is used not only for the flow controllers 2203 and 2204, but also our flow meters with needle valve. It is a must for strict flow rate adjustment.






Principle of the Flow controller for fluctuating outlet pressure (2203)

When the gas is supplied from the IN side by the constantly kept pressure, the primary-side chamber is filled with the supply pressure and the gas enters the secondary-side chamber through the needle valve. The primary-side and secondary-side chambers are partitioned by a diaphragm. A spring force is applied to the pressure in the secondary-side chamber balanced with the constant pressure in the


primary-side chamber. The nozzle part adjusts a gas outflow so that the pressure in the secondary-side chamber is kept balanced, and the differential pressure before and after the needle valve is always kept constant. As this indicates that a gas flow rate is only associated with the opening of the needle valve, it is not affected by the outlet pressure.



Principle of the Flow controller for fluctuating supply pressure (2204)

The fluctuating pressure gas supplied from the IN side enters the primary-side chamber through the nozzle part. Passing through the needle valve, it is discharged to the OUT side, and part of it enters the secondary-side chamber. The primary-side and secondary-side chambers are partitioned by a diaphragm. The secondary-side chamber is exposed to a constant pressure and a spring force. In order to keep a balance with this, the pressure of the gas entering the

primary-side chamber is adjusted by the nozzle part. Striking a pressure balance between the secondary-side and primary-side chambers, the differential pressure before and after the needle valve is always kept constant. As this indicates that a gas flow rate is only associated with the opening of the needle valve, it is not affected by the supply pressure.




Precautions for handling the flow control valves

- The needle valve cannot assure a constant flow rate continuously. Opening/closing of other valves, temperature change, impact, etc. may be the factors to change the flow rate. Set a period to monitor and readjust it.
- The needle valve is designed to "control a fluid." It does not assure complete shutoff. To stop a flow of the fluid, install a stop valve additionally. Note that if the needle valve is turned more than necessary, the product may be damaged.


Precision Needle Valve

MODEL 2412 SERIES Applicable fluids Gas N₂, Air, H₂, He, Ar, O₂, CO₂, etc. Liquid H₂O Max. flow rate Gas 5mL/min to 100L/min (Air at 20°C, 0.1MPa differential pressure) * Up to the working conditions. For details, see the reference data. Stable control of minute flow rate Superior control performance by a non-rotating structure Capable of selecting optimum controllability according to the working conditions with wide variety of needles

Dimensions



Example of use



Standard Specifications

MODEL	241	2			
Applicable fluids	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.				
Number of turns of regulating screw	Approx. 12 turns				
Max. working pressure	1MPa(G)				
Max. working temperature	SS: 120°C				
wax. working temperature	B: 70°C				
Materials of parts in contact with fluid	SS: SUS316, PCTFE, FKM				
waterials of parts in contact with huld	B: Brass, POM, NBR, SUS316				
Connection	Rc1/4				
Weight	Approx. 150g				

Flow ratings table (reference)

Flow rate when the valve is fully opened to atmosphere.


Unit of flow rate: L/min


Needle No.			Supply pre	ssure (MPa(G)) (A	ir at 20°C)			Supply pre	essure (MPa(G)) (H ₂ O at 20°C)
needle No.	0.05	0.1	0.2	0.3	0.4	0.5	0.6	0.05	0.1	0.15
#SS1	0.023	0.047	0.078	0.11	0.15	0.19	0.22	-	=	-
#S1	0.068	0.11	0.20	0.27	0.34	0.40	0.47	-	-	-
#1	0.15	0.23	0.36	0.51	0.65	0.79	0.93	0.00145	0.0026	0.0036
#2	0.34	0.46	0.71	1.0	1.2	1.5	1.75	0.0076	0.012	0.0153
#2A	0.45	0.65	1.0	1.3	1.65	2.0	2.3	0.0132	0.0195	0.0245
#3	0.9	1.3	2.0	2.6	3.25	3.9	4.6	0.0260	0.0390	0.0510
#3A	1.25	1.9	2.75	3.65	4.5	5.3	6.4	0.0365	0.0546	0.0740
#3B	1.85	2.5	3.7	5.0	6.0	7.2	8.3	0.053	0.0760	0.0980
#4	4.3	6.2	9.0	12.0	15.0	18.3	22.0	0.124	0.188	0.234
#4A	8.0	11.0	15.0	21.0	26.0	31.0	36.0	0.228	0.336	0.417
#5	10.0	14.0	21.0	27.0	33.0	40.0	46.0	0.294	0.435	0.576
#6	22.0	31.0	45.0	60.0	75.0	92.0	105.0	0.564	0.834	1.100
#6A	30.0	41.0	60.0	80.0	100	118	138	0.774	1.190	_
#6B	38.0	53.0	82.0	106	135	160	185	1.280	1.950	-
#7	80.0	110	160	215	260	285	310	1.840	2.890	_


^{*} An actual flow rate may deviate from the values in the table within a range of 80% to 130% depending on the working conditions and instrumental errors. Use them as reference values.


CV value (reference)

Needle No.	MAX CV value		
#SS1	0.00012		
#S1	0.00022		
#1	0.00058		
#2	0.0012		
#2A	0.0016		
#3	0.0033		
#3A	0.0048		
#3B	0.0063		
#4	0.016		
#4A	0.028		
#5	0.035		
#6	0.078		
#6A	0.10		
#6B	0.13		
#7	0.28		










Ordering



^{*} We will select an optimum needle number based on the conditions such as the pressure, fluid and flow rate. Use the ratings table only as reference.

^{*} The above table shows a data example of the 2412L. Due to a structural difference, if a flow rate increases, 2412L shows better flow characteristics than the 2412T. So 2412L is recommended for over 5L/min flow rate condition.

^{*} No shutting O-ring for FFKM option.

Performance comparison data of 2412 and 2400 (reference)

Followings are the comparison survey at low pressure conditions.

See them as the performance comparison reference data of the precision needle valve 2412 and the simplified needle valve 2400. They are typical values, not guaranteed ones.


[Items] 2412T-SS-1/4-Air-#4 2400T-S-1/4-N1


[Hysteresis characteristics]


(Fluid) Air (Supply pressure) 1kPa (Hysteresis check) Needle open \rightarrow Close \rightarrow Open

2412T

Supply pressure 1.0 [kPa] Air flow rate [mL/min] Number of turns Open → Close Close → Open 0 435 415 390 360 3 315 285 265 5 220 205 124 118 37 38 10 13 12 11 13 0 0 14









[Temperature condition flow rate stability test]

(Ambient temperature setting) Starting from 20°C, repeat 5 cycles of 20°C \rightarrow 50°C, 3 hours \rightarrow 20°C, 3 hours.





2400T

(Supplementary explanation)

In the above data, Model 2412 is superior in both the restorability of hysteresis and the flow rate stability under temperature change condition. This is because the precision needle 2412 has an adjusting shaft and a needle separated, converts a rotating direction into a translatory motion and its conversion threads are provided with a backlash-free mechanism, allowing very stable adjustment and setting, whereas the simplified needle 2400 is a single-axis rotary needle where a knob adjusting shaft itself is a needle shaft. (See Page 93 for the detailed principle) The valve part of the 2412 is used for the precision flow meters such as RK1200 and the flow controllers of the valves 2203, 2204 and 2600. The 2400 is used for simple flow meters such as RK1600R. Select the models conforming to your specifications (performance, cost, etc.). It is recommended to test at harsh working conditions with an actual machine.

Precision Needle Valve with Multidial

MODEL 2412M SERIES



Applicable fluids Gas N₂, Air, H₂, He, Ar, O₂, CO₂, etc. Liquid H₂O

Max. flow rate

Gas 5mL/min to 100L/min
(Air at 20°C, 0.1MPa differential pressure)

Liquid 5mL/min to 2L/min (H₂O at 20°C, 0.1MPa differential pressure)


* Up to the working conditions. For details, see the reference data.




- Capable of setting flow rate at the scale of multidial
- Stable control of minute flow rate
- Superior control performance by a non-rotating structure
- Capable of selecting optimum controllability according to the working conditions with wide variety of needles



Dimensions



Example of flow rate characteristics




Standard Specifications

MODEL	2412M				
Applicable fluids	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.				
Number of turns of regulating screw	Approx. 12 turns				
Max. working pressure	1MPa(G)				
May working tomporature	SS: 120°C				
Max. working temperature	B: 70°C				
Motoriolo of porto in contrat with fluid	SS: SUS316, PCTFE, FKM				
Materials of parts in contact with fluid	B: Brass, POM, NBR, SUS316				
Connection	Rc1/4				
Weight	Approx. 170g				

^{*} Dial scale range: 000 to 999 (no scale calibration)

Ordering



^{*} We will select an optimum needle number based on the conditions such as the pressure, fluid and flow rate. Use the ratings table only as reference

^{*} The 2412M and 2412 have opposite screw turning directions to each other.


^{*} See the 2412 for the flow rating.

2450T


Bellows Needle Valve

MODEL 2450 SERIES Applicable fluids Gas N₂, Air, H₂, He, Ar, O₂, CO₂, etc. Liquid H₂O Max. flow rate Gas 5mL/min to 50L/min (Air at 20°C, 0.1MPa differential pressure) *Up to the working conditions. For details, see the reference data. Low leak thanks to bellows seal Stable control of minute flow rate Superior control performance by a non-rotating structure Capable of selecting optimum controllability according to the working conditions with wide variety of needles

Dimensions



Example of use



Standard Specifications

MODEL	2450				
Applicable fluids	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.	H ₂ O			
Number of turns of regulating screw	Approx. 13 to 16 turns (effective turns: 5 to 16)				
Max. working pressure	1MPa(G)				
Max. working temperature	120°C				
Materials of parts in contact with fluid	SUS316, PCTFE, FKM				
	Standard: 1/4SWL type				
Connection	Option: 1/8SWL type				
Weight	Approx. 270g				

Flow ratings table (reference)


Flow rate when the valve is fully opened to atmosphere.

Unit of flow rate: L/min


Noodle No		Supply pressure (MPa(G)) (Air at 20°C)								Supply pressure (MPa(G)) (H ₂ O at 20°C)		
Needle No.	0.05	0.1	0.2	0.3	0.4	0.5	0.6	0.05	0.1	0.15		
BSS1	0.016	0.032	0.058	0.086	0.115	0.14	0.18	_	-	-		
BS1	0.074	0.12	0.20	0.28	0.34	0.44	0.52	-	-	-		
B1	0.10	0.16	0.24	0.34	0.42	0.53	0.60	-	=	-		
B2	0.12	0.19	0.29	0.41	0.50	0.63	0.72	0.0010	0.0017	0.0024		
B2A	0.25	0.39	0.60	0.82	1.05	1.30	1.50	0.010	0.015	0.018		
В3	0.67	0.98	1.55	2.10	2.65	3.20	3.70	0.019	0.029	0.037		
ВЗВ	1.10	1.7	2.5	3.4	4.3	5.1	5.9	0.034	0.05	0.067		
B4	4.4	6.3	9.4	12.0	16.0	19.2	22.0	0.15	0.21	0.27		
B4A	6.7	9.8	13.9	19.0	24.0	27.9	31.6	0.23	0.32	0.40		
B5	7.8	11.3	16.5	20.0	28.0	33.0	38.0	0.26	0.35	0.46		
B6	15.3	20.5	32.0	44.0	55.0	68.0	80.0	0.46	0.66	0.79		
B6A	21.0	32.0	51.0	70.0	90.0	110	128	0.72	1.0	1.15		
B7	40.0	55.0	100	130	170	195	230	1.18	1.7	1.95		

^{*} An actual flow rate may deviate from the values in the table within a range of 80% to 130% depending on the working conditions and instrumental errors. Use them as reference values.

CV value (reference)




Ordering




- * We will select an optimum needle number based on the conditions such as the pressure, fluid and flow rate. Use the ratings table only as reference.
- * No shutting O-ring for FFKM option.
- * 'SWL type' is shortened to SW in Ordering code.

^{*} The above table shows a data example of the 2450L. Due to a structural difference, if a flow rate increases, 2450L shows better flow characteristics than the 2450T. So 2450L is recommended for over 5L/min flow rate condition.


Grease-less Needle Valve



Dimensions



Example of use



Standard Specifications

MODEL	2420				
Applicable fluids	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.	H ₂ O			
Number of turns of regulating screw	Approx. 10 turns				
Max. working pressure	0.6MPa(G)				
Max. working temperature	80°C				
Materials of parts in contact with fluid	SUS304, PP, FKM (Partly coated with PTFE)				
Connection	Rc1/4				
Weight	Approx. 100g				

Flow ratings table (reference)

Flow rate when the valve is fully opened to atmosphere.


Unit of flow rate: L/min


Needle No.		Su	Supply pressure (MPa(G)) (H:O at 20°C)						
	0.05	0.1	0.2	0.3	0.4	0.5	0.05	0.1	0.15
N1	18	26	38	50	62	76	0.60	0.87	1.06
N2	28	40	62	82	102	124	0.98	1.38	1.69
N3	62	92	140	186	234	280	1.91	2.70	3.30
N4	76	112	178	240	298	360	2.31	3.28	4.05
N5	122	182	274	366	462	558	2.95	4.22	5.23


^{*} An actual flow rate may deviate from the values in the table depending on the working conditions and instrumental errors. Use them as reference values.


Example of flow rate characteristics (Air, 0.1MPa(G), 20°C)


Example of flow rate characteristics (H₂O, 0.1MPa(G), 20°C)


























CV value (reference)

Needle No. MAX CV value N1 0.059 N2 0.097 N3 0.188 N4 0.228


0.290

Working flow rate (reference)

Needle No.	Air (0.1MPa(G) at 20°C)	H ₂ O (0.1MPa(G) at 20°C)
N1	from 200mL/min	from 10mL/min
N2	from 1L/min	from 30mL/min
N3	from 1.5L/min	from 50mL/min
N4	from 5L/min	from 150mL/min
N5	from 51 /min	from 150ml /min

Ordering

N5




^{*} This product is excluded from our scope of repair.

Simplified Needle Valve

MODEL 2400 / 2400A SERIES Applicable fluids Appli

Dimensions



Standard Specifications

MODEL	2400, 2400A				
Applicable fluids	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.	H ₂ O			
Number of turns of regulating screw	Approx. 12 turns (effective turns: 5 to 12)				
Max. working pressure	0.6MPa(G)				
Max. working temperature	S: 60°C				
wax. working temperature	B: 60°C				
Materials of parts in contact with fluid	2400A: SUS304, FKM, SUS303, PCTFE				
materials of parts in contact with hulu	2400: Brass, NBR, SUS303, POM				
Connection	Rc1/4				
Weight	Approx. 100g				

Flow ratings table (reference)

Flow rate when the valve is fully opened to atmosphere.

Unit of flow rate: L/min


2400AL-S

2400T-B

Needle No	Max.	Supply pressure (MPa(G)) (Air at 20°C)					Supply pressure (MPa(G)) (H ₂ 0 at 20°C)		
	CV value	0.01	0.05	0.1	0.2	0.3	0.05	0.1	0.15
N1	0.018	1.6	5.0	7.5	12.0	15.0	0.16	0.24	0.31
N2	0.03	3.8	9.0	13.0	21.0	27.0	0.26	0.42	0.86
N3	0.13	12.0	31.0	55.0	90	120	1.2	1.8	2.5

^{*} An actual flow rate may deviate from the values in the table depending on the working conditions and instrumental errors. Use them as reference values.


Ordering



Precision Needle Valve for Large flow rate

MODEL 2412D SERIES Applicable fluids Gas N₂, Air, H₂, He, Ar, O₂, CO₂, etc. Liquid H₂O Max. flow rate Gas 150 to 350L/min (Air at 20°C, 0.1MPa differential pressure) * Up to the working conditions. For details, see the reference data. Stable control of large flow rate Superior control performance by a non-rotating structure

Dimensions



Standard Specifications


MODEL	2412D		
Applicable fluids	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.	H ₂ O	
Number of turns of regulating screw	Approx. 8 to 12 turns		
Max. working pressure	1MPa(G)		
May working townsysters	SS: 120°C		
Max. working temperature	A: 70°C		
Matariala of parts in contact with fluid	SS: SUS316, FKM, PCTFE		
Materials of parts in contact with fluid	A: AI, Brass, SUS316, NBR, POM		
Connection	Standard: Rc3/8, Option: Rc1/4		

Flow ratings table (reference)


low rate when the valve is fully opened to atmosphere.						Un	it of flow r	ate: L/mi	
Needle	Max.	5	Supply pres	sure (MPa(G)) (Air at 2	20°C)	Supply pres	sure (MPa(G))	(H ₂ O at 20°C)
No.	CV value	0.01	0.05	0.1	0.2	0.3	0.01	0.05	0.1
#8	0.48	50	135	200	280	370	2.2	4.9	6.9
#9	0.63	72	180	270	423	-	2.9	6.4	9.1
#10	1.06	80	300	440	-	-	4.8	10.8	15.3

^{*} An actual flow rate may deviate from the values in the table depending on the working conditions and instrumental errors. Use them as reference values.

CV value (reference)



Ordering



^{*} We will select an optimum needle number based on the conditions such as the pressure, fluid and flow rate. Use the ratings table only as reference.

Flow Controller for Fluctuating outlet pressure

MODEL 2203 SERIES




Applicable fluids Gas N₂, Air, H₂, He, Ar, O₂, CO₂, etc.

Max. flow rate Gas 10mL/min to 20L/min (Air at 20°C)

- Capable of holding a constant flow rate against pressure fluctuations on the outlet (secondary) side
- Superior control performance by a non-rotating structure




Dimensions



Standard Specifications

Standard Specifications	
MODEL	2203
Applicable fluids	N ₂ , A/r, H ₂ , He, Ar, O ₂ , CO ₂ , etc.
Max. flow rate (air at 20°C)	10mL/min to 20L/min
Control accuracy	Within 1% of indication value against load pressure fluctuations (inlet / outlet differential pressure: 0.05MPa or more)
Number of turns of regulating screw	Approx. 12 turns
Max. working pressure	0.8MPa(G)
Max. working temperature	60°C
	SS: SUS316, PCTFE, FKM
Materials of parts in contact with fluid	A: AI, Brass, SUS316, POM, NBR
Connection	Rc1/8 (M8 + Rc1/8)
Weight	Approx. 160g

Ordering



 $^{^{\}star}$ Inlet / outlet differential pressure needs to be 0.05MPa or more.

Flow Controller for Fluctuating supply pressure

MODEL 2204 SERIES




Max. flow rate Gas 10mL/min to 10L/min (Air at 20°C)


- Capable of holding a constant flow rate against pressure fluctuations on the inlet (primary) side
- Superior control performance by a non-rotating structure



Dimensions




Example of control characteristics



Standard Specifications

MODEL	2204
Applicable fluids	N ₂ , Air, H ₂ , He, Ar, O ₂ , CO ₂ , etc.
Max. flow rate (air at 20°C)	10mL/min to 10L/min
Control accuracy	Within ±2% of indication value at 0.3MPa change between the inlet pressure of 0.07MPa and 0.8MPa
Number of turns of regulating screw	Approx. 12 turns
Max. working pressure	0.8MPa(G)
Max. working temperature	60°C
	SS: SUS316, PCTFE, FKM, Hard glass
Materials of parts in contact with fluid	A: AI, Brass, SUS316, POM, NBR, Hard glass
Connection	Rc1/8 (M8 + Rc1/8)
Weight	Approx. 210g

Ordering



 $^{^{\}star}$ Inlet / outlet differential pressure needs to be 0.07MPa or more.

Liquid Flow Controller

MODEL 2600-S SERIES




Applicable fluids Liquid H₂O

Max. flow rate Liquid 10mL/min to 1L/min (H₂O at 20°C)


- Capable of holding a constant flow rate against pressure fluctuations
- Capable of controlling from minute flow rate




Dimensions



Example of use






Standard Specifications

MODEL	2600-S			
Applicable fluids	H ₂ O			
Flow rating	1 to 10mL/min, 10 to 100mL/min, 50 to 500mL/min, 0.1 to 1L/min			
Control accuracy	Within ±3%F.S. (liquid temperature should be constant)			
Operating differential pressure	0.1MPa or more			
Working pressure	0.1 to 0.5MPa(G)			
Proof pressure	0.7MPa(G)			
Working temperature	15 to 35°C			
Materials of parts in contact with fluid	S: SUS316, FKM, FFKM, PTFE			
Connection	Rc1/4			

Ordering



Liquid Flow Controller

MODEL 2600-PPS SERIES




Applicable fluids Liquid H₂O

Max. flow rate Liquid 10mL/min to 1L/min (H₂O at 20°C)


- Capable of holding a constant flow rate against pressure fluctuations
- Capable of controlling from minute flow rate




Dimensions



Example of use




Example of control characteristics



Standard Specifications

MODEL	2600-PPS	
Applicable fluids	H ₂ O	
Flow rating	1 to 10mL/min, 10 to 100mL/min, 50 to 500mL/min, 0.1 to 1L/min	
Control accuracy	Within ±3%F.S. (liquid temperature should be constant)	
Operating differential pressure	0.1MPa or more	
Working pressure	0.1 to 0.5MPa(G)	
Proof pressure	0.7MPa(G)	
Working temperature	15 to 50°C	
Materials of parts in contact with fluid	PPS (30% glass contained), SUS316, FKM, FFKM, PTFE	
Connection	Rc1/8 (M8 + Rc1/8)	


Ordering



Small Proportional Solenoid Valve


MODEL 3000 SERIES Applicable fluids Gas N₂, Air, H₂, He, Ar, O₂, CO₂, etc. Small, light-weight, single power supply Low power consumption (Max. 2W) Hysteresis within 15% Standard type Connection port: 63.0 Joint type

Dimensions




Example of use

1. Gas flow rate control



2. Gas pressure control



Connection port: Rc1/8


Standard Specifications

MODEL		3010	3020	3030	3040	3050
Orifice diameter (ø mn	1)	0.08	0.28	0.5	0.75	1.3
Maximum CV value		0.00022	0.0021	0.0086	0.02	0.042
Pressure	Proof pressure			0.98MPa(G)*1		
riessuie	Operating differential pressure	up to 0	.98MPa	up to (0.6MPa	up to 0.4MPa
	Maximum control voltage			12/24V		
Control	Power consumption			Max.1W/2W		
	Hystesresis		Wit	hin 15%, full-scale curi	rent	
Filter			20μ (IN, OUT)		Withou	ıt filter
Internal leak		0.1mL/min or les	s within proof pressure	of applicable gas	0.2mL/m	in or less
Working temperature				0°C to 50°C*2		
Storage temperature				-5°C to 70°C		
Materials of parts in	BS		C3604, S	SUS430F, FKM, SUS316,	SUS304	
contact with fluid	SUS		SUS	430F, FKM, SUS316, SU	S304	
Dimensions (mm)			[□13 × 17.5 + ø19 × 3	1	
Lead wire				UL3266 XLPE #28		
Insulation class				Class A		
Connection			ø3.0 manifo	ld (standard), ø3 hose n	ipple, Rc1/8	
Weight			Ар	prox. 60g (140g for Rc1	/8)	

^{*1.} Proof pressure is a value of the valve body. In the case of the hose nipple type, refer to the proof pressure of the hose.

In case the ambient temperature changes greatly, current control is recommended. Consult our sales office.


Ordering



 $^{^{\}star}$ Let us know the fluid name, supply pressure, outlet pressure and maximum flow rate at ordering time.


^{*2.} A coil copper wire resistance value has a temperature coefficient of Rt = Ro°C (1 + 0.004 × t°C). When using voltage control, make sure that the ambient temperature does not vary widely.

Example of PWM controlled flow rate characteristics





Duty (%)	Flow (mL/min)			3010
0	0		350	
45	2		300	
50	9.1		250	
55	40.4			<i>f</i>
60	82	Air FI	200	
65	127.8	Air Flow (L/min)	150	7
70	176.2	(L/IIIII)		<i>†</i>
75	220		100	•
80	255.4		50	
85	278.7			
90	295.5		0	00000000000000
95	305.4			Duty (%)

	Flow (L/min)	Duty (%)
	0	0
	0.072	45
	0.652	50
-	1.484	55
Air Flow	2.391	60
(L/mi	3.272	65
(21111	3.931	70
	4.37	75
	4.67	80
	4.864	85
	5.007	90
	5.116	95




Example of flow rate characteristics







List of Pressure Control Valve











About Pressure Control Valve

Types of Pressure Control Valves

The pressure control valve controls the pressure constant or reduces the pressure during flow rate control. The pressure control valves generally include reducing valves (pressure regulators) and back pressure valves (back pressure regulators). They are represented by the symbols illustrated below, respectively.

The reducing valve is a regulating valve designed to keep the outlet-side pressure constant against the fluctuating pressure on the supply side. It is normally used in the first stage of the system in many cases.

On the other hand, the back pressure valve is designed to release the primary-side pressure (gas) through the valve to keep it constant when it exceeds the set value.

Since the reducing valve controls the outlet-side pressure, it is used with a pressure gauge attached to the outlet side. Model 6600 comes with a gauge port. In such a case, connect the pressure gauge to this port. The pressure of this port is virtually equivalent to the outlet.




Flow rate characteristics chart

The flow rate characteristics graph of the reducing valve shown in the catalog is measured by the illustrated flow sheet below.


In the example of flow rate characteristics graph, the primary pressure (supply pressure) is 686kPa(G). With the needle valve closed (zero flow rate), the secondary pressure is set by the reducing valve as load resistance in its latter stage. This value becomes zero flow rate in the graph, that is, a left-end value. Next, open the needle valve to run a gas and plot the changing state of the pressure (secondary pressure) set according to a flow rate. The most desired state is that the set pressure does not change depending on the flow rate (change

of load resistance). Depending on the characteristics of the reducing valve, however, there is a slight effect up to a certain flow rate, and once reaching a limit, the pressure changes. The range with the least change is the working range of the reducing valve. In the example of flow rate characteristics graph, if the setting pressure is 294kPa(G) when the primary-side pressure is 686kPa(G), the characteristics are favorable at the flow rate below a circle mark (O) in the graph. If the flow rate exceeds 11L/min, however, the pressure characteristics deteriorate. Use at 11L/min or less.

Flow rate characteristics test flow sheet




Example of flow rate characteristics



Pressure characteristics chart

In the case of the reducing valve, the figure shows secondary-side pressure fluctuations when the primary-side pressure in the aforementioned flow sheet is changed.

Control characteristics differ slightly between primary pressure increase and decrease. The change status is indicated by arrows.



Principle of the pressure regulator (6600)


If a knob is turned counterclockwise, a pressure regulating spring is loosened, allowing only the atmospheric pressure to be applied to the diaphragm surface.

When this is done, a stem is pushed up by the gas supplied from the IN side, bringing a ball into contact with an O-ring to seal the nozzle part, thereby blocking a gas flow to the OUT side.

If the knob is turned clockwise, the pressure regulating spring is held down, applying the atmospheric pressure plus the pressure of the pressure regulating spring to the diaphragm surface.

The diaphragm held down by the pressure regulating spring pushes down the stem, opening a path in the nozzle part.


Since the pressure applied to the diaphragm surface is always kept constant by the atmospheric pressure plus the pressure regulating spring inside the bonnet, the secondary-side pressure is kept constant by the stem, even if the primary-side pressure fluctuates.



Principle of the backpressure regulator (6800)

Operation is opposite to the 6600.

The pressure applied to the diaphragm surface is always kept constant by the atmospheric pressure plus the pressure regulating spring inside the bonnet. The pressure is regulated by a valve spring inside the main body so that the primary-side pressure will be kept constant, and the fluctuated pressure is exhausted to the OUT side through the nozzle part to adjust.



Precision Pressure Regulator

ODEL 6600 SERIES




Gas Secondary side: 0.01 to 0.6MPa(G)


Gas 10L/min, 20L/min Max. flow rate


- High controllability of ±1% repeatability against primary- and secondary-side pressure fluctuations
- Optimum inlet and outlet arrangement for mounting to the panel
- Non-bleed design



Dimensions








Dimensions of	each pa	rt			
MODEL	А	В	С	D	Е
6600A	28	30.5	11	OUT	IN
6600B	31	30.5	11	OUT	IN
6600AL	28	33.5	14	IN	OUT
6600BL	31	33.5	14	IN	OUT

Example of use





(Cutting dimensions)


Standard Specifications


MODEL	6600A	6600B	6600AL	6600BL	
Primary-side maximum pressure		0.8M	Pa(G)		
Secondary-side setting pressure	0.01 to 0.3MPa(G)	0.03 to 0.6MPa(G)	0.01 to 0.3MPa(G)	0.03 to 0.6MPa(G)	
Max. flow rate	10L/min 20L/min		/min		
Repeatability		Within ±1% of the rated pressure			
Temperature characteristics	Within ±1% / 10°C of the rated pressure				
Minimum operating differential pressure	0.05MPa				
Proof pressure		0.8M	Pa(G)		
Ambient temperature		5 to	60°C		
Materials of parts in contact with fluid		SS: SUS316, FKM, PCTF	E, SUS303, (Hard glass)		
materials of parts in contact with huld		A: AI, Brass, NBR, POM	I, SUS316, (Hard glass)		
Connection		Standar	d: Rc1/4		
Connection		Option	n: Rc1/8		
Weight		Approx	c. 200g		

Example of flow rate characteristics











Example of pressure characteristics



Ordering



Pressure Regulator for Large flow rate

MODEL 6700 SERIES



Setting pressure Gas Secondary side: 0.01 to 0.6MPa(G)


Max. flow rate

Gas 50L/min

- High controllability of ±1% repeatability against primary- and secondary-side pressure fluctuations
- Non-bleed design




Dimensions




Standard Specifications


MODEL	6700A	6700B		
Primary-side maximum pressure	0.9MPa(G)			
Secondary-side setting pressure	0.01 to 0.3MPa(G)	0.05 to 0.6MPa(G)		
Max. flow rate	50L/min			
Repeatability	Within ±1% of the rated pressure			
Minimum operating differential pressure	0.05MPa			
Proof pressure	1MPa(G)			
Ambient temperature	5 to	60°C		
Materials of parts in contact with fluid	SS: SUS316, FKM, PCTFE, (SUS304)			
materials of parts in contact with huid	A: AI, Brass, NBR, POM, SUS316, FKM, (SUS304)			
Connection	Standard: Rc3/8, Option: Rc1/4			
Weight	Approx	. 250g		

Example of flow rate characteristics





Ordering



Precision Pressure Regulator for Low pressure

MODEL 6610




Setting pressure Gas Secondary side: 0.01 to 0.15MPa(G)

Max. flow rate Gas 5L/min

- High controllability of ±1% repeatability against primary- and secondary-side pressure fluctuations
- Grease-less gas contact part
- Non-bleed design
- Structured with lock nut




Dimensions




Standard Specifications

Standard Specifications		
MODEL	6610	
Primary-side maximum pressure	0.4MPa(G)	
Secondary-side setting pressure	0.01 to 0.15MPa(G)	
Max. flow rate	5L/min	
Repeatability	Within ±1% of the rated pressure	
Minimum operating differential pressure	0.1MPa	
Proof pressure	0.8MPa(G)	
Ambient temperature	5 to 60°C	
Materials of parts in contact with fluid	SUS316, FKM, Hard glass, PTFE, PCTFE, SUS304, SUS303	
Connection	Rc1/8	
Weight	Approx. 350g	

Example of flow rate characteristics



Ordering



Backpressure Regulator

6800 SERIES



Gas Primary side: 0.01 to 0.6MPa(G) **Setting pressure**

Gas 0.8L/min, 1L/min, 10L/min Max. flow rate


- Constant primary-side pressure
- Optimum inlet and outlet arrangement for mounting to the panel




Dimensions

6800A


6800B



Example of use



(2) Example of obtaining a constant flow rate of the mixed gas by a constant flow valve



Standard Specifications


28 30.5 25

11 IN OUT 10 31 30.5 30 11 IN OUT 13 40


28 34.5 25 14 OUT IN 10 31 34.5 30 14 OUT IN 13 40

MODEL	6800A	6800B	6800AL	6800BL	
Primary-side setting pressure	0.01 to 0.3MPa(G)	0.01 to 0.6MPa(G)	0.01 to 0.3MPa(G)	0.01 to 0.6MPa(G)	
Maximum exhaust flow	1L/min	0.8L/min	10L/	min	
Proof pressure	0.8MPa(G)				
Ambient temperature	5 to 60°C				
Bankaniala of manta in annuant with fluid		SS: SUS316, FK	M, SUS303		
Materials of parts in contact with fluid		A: AI, Brass, N	BR, SUS316		
Connection		Standard: Rc1/4,	Option: Rc1/8		
Weight	Approx. 400g				


Example of pressure characteristics



Example of flow rate characteristics



Ordering



Cylinder Regulator with Precision Flow Meter

MODEL 7700 SERIES Setting pressure Secondary side: 0.01 to 0.15MPa(G)




Max. flow rate Gas 20L/min

Cylinder regulator provided with Model 4400 series



Dimensions




Standard Specifications

Catting and and	May flavorate	Pressur	re gauge	Metarial
Setting pressure range	Max. flow rate	Primary side	Secondary side	Material
0.02 to 0.15MPa	20L/min	0 to 25MPa(G)	0 to 0.25MPa(G)	Brass
0.01 to 0.06MPa	20L/min	0 to 25MPa(G)	0 to 0.1MPa(G)	SUS316

- * The Model 7700 has an exclusive flow meter (Model 4400) attached to a cylinder regulator. Other combinations are also available. Inquire our sales office.
- * Depending on the gas type, pressure reducing operation lowers the gas temperature extremely due to the Joule-Thomson effect and deteriorates the regulator's function, disturbing a gas flow.

Flow meter specifications



As illustrated on the left, the flow meter's valve is attached to the inlet side. The scale is manufactured on the premise of a fluid flow in the atmospheric state. If a tank, etc. subjected to resistance or back pressure are located on the downstream side, the following flow rate correction is required.


Actual flow rate = Indicated flow rate value on taper tube $\times \sqrt{\frac{0.1 + secondary side pressure}{0.1}}$


In case the secondary-side pressure gauge indicates

0.3MPa and the indicated flow rate value is 3L/min, 6L/min = 3L \times $\sqrt{\frac{0.1+0.3}{0.1}}$

is established, and the actual flow rate becomes greater than the indicated flow rate.


Ordering







The Gas Generator / Engineering Device

List of Gas Generator / Engineering Device







The Gas Generator / Engineering Device

Compact Gas Generator


Mini-CUBE® SERIES N2 O2 O3 CDA

The Mini-CUBE series is an ultra-small gas generator installable on the desk. It is capable of easily supplying high-quality gases such as nitrogen, oxygen, ozone and clean dry air (CDA). Also, it lines up a tank unit as an auxiliary.

- Reduced noise and conserving energy by up to 40% thanks to DC inverter-controlled compressor.
- Double sound-proof structure. Noise value: 55 dB*1
- Push one switch to start gas supply. Freeing you from cylinder management.
- 100VAC to 240VAC, 50/60Hz free power voltage.
- \blacksquare Compact design: 310(W) × 392(D) × 310(H)mm (For NCP, 310(W) × 270(D) × 310(H)mm)
- 25kg light-weight design allows transportation by home delivery service, and also allows to return for maintenance.
- Air supply type (no compressor) lined up for N₂, O₂ and CDA. (Type indication: NCP)



Dimensions



Nitrogen Gas Generators Standard Specifications

- Supply to various analyzers (GC / FT-IR / DSC)
- Supply to incubator and bioreactor · Purge gas to various reaction container
- · CO2 incubator

- · Non-oxidation storeroom
- · Non-oxidation pumping of solvent and powder · Electronic part soldering atmospheric gas

■ Nitrogen gas generator MNTS

MNTS is a nitrogen gas generator capable of selecting purity of 95% to 99.999%. Its maximum discharge pressure is 0.5MPa.

· Gas flush packaging of small foodstuff

MODEL	M1NTS-0.3-95	M1NTS-0.3-96	M1NTS-0.3-97	M1NTS-0.3-98	M2NTS-0.3	M3NTS-0.3	M4NTS-0.3	M5NTS-0.3
Purity*2	95%	96%	97%	98%	99%	99.9%	99.99%	99.999%
Generating volume*3	8NL/min	7NL/min	6NL/min	5NL/min	4NL/min	2.4NL/min	1.2NL/min	0.5NL/min
Pressure			0.3MPa			0.4MPa	0.5	MPa
Dew point				-55°C	or less			
Power consumption				0.06 to	0.3kW			

^{*} As described in the specification sheet, the display of an incorporated oxygen densitometer is a guide for 99.999% model.

■ Nitrogen gas generator MNTS-NCP

MNTS-NCP is the air supply type (no compressor) of the MNTS type. The numbers in () are specification of the W type.

MODEL	M1NTS-NCP(W)-95	M1NTS-NCP(W)-96	M1NTS-NCP(W)-97	M1NTS-NCP(W)-98	M2NTS-NCP(W)	M3NTS-NCP(W)	M4NTS-NCP(W)	M5NTS-NCP(W)
Purity*2	95%	96%	97%	98%	99%	99.9%	99.99%	99.999%
Generating volume*3	8(14.5)NL/min	7(13)NL/min	6(11.5)NL/min	5(10)NL/min	4(8)NL/min	2.4(4.8)NL/min	1.2(2.4)NL/min	0.5(1)NL/min
Pressure	0.3(0.	2)MPa		0.3MPa		0.4MPa	0.5	MPa
Dew point				-55°C	or less			
Power consumption				0.1(0.0	35)kW			

^{*} As described in the specification sheet, the display of an incorporated oxygen densitometer is a guide for 99.999% model.

Oxygen Gas Generators Standard Specifications

<Usage>

- · Supply to incubator and bioreactor
- · Oxygen enrichment for fishery
- Oxygen-enriched combustion
- · As raw material for ozone
- · CO₂ elimination

Oxygen gas generators MOXS and MOXS-NCP

MOX is an oxygen gas generator capable of supplying oxygen gases with purity of 90% or more. The numbers in () are specification of the W type.

MODEL	MOXS-0.3	MOXS-NCP(W)			
Purity	90% or more				
Generating volume*3	0.2 to 2NL/min	0.2 to 2(3)NL/min			
Pressure	0.1MPa				
Dew point	-55°C or less				
Power consumption	0.06 to 0.3kW	0.1(0.035)kW			

Ozone Gas Generators Standard Specifications

<Usage>

- · Chemical (oxidation process)
- · Drainage treatment, deodorization
- (decolorization, decomposition) · Fishery (sterilization, purification)
- · Cleaning and cotton-filling
- (deodorization, bleaching, sterilization) · Oxidation corrosion durability test
- · Resin processing (lamination)

Ozone gas generator MOZS

MOZS is an ozone gas generator. It generates ozone, using oxygen generated by an incorporated oxygen generator as a raw material.

MODEL	MOZLS-0.3	M0ZHS-0.3		
Generating volume	0 to 2.0g/h	0 to 1.5g/h		
Ozone concentration	0 to 25g/Nm ³	0 to 50g/Nm ³ 0.5NL/min 5MPa(G)		
Gas flow rate	1.5NL/min	0.5NL/min		
Ozone gas pressure	up to 0.0	05MPa(G)		
Cooling method	Air-c	ooled		
Power consumption	0.06 to	0.3kW		

^{*} Because of the air-cooled cylindrical silent discharge method, the ozone concentration (ozone generating amount) changes depending on the installation ambient temperature. As the temperature rises, the concentration is lowered and the device life is shortened.

Clean Dry Air Generators Standard Specifications

- · Supply to various analyzers
- · Frost prevention of freezers
- · Humidity control

■ Clean dry air generators MAIRS and MAIRS-NCP

MAIRS is a clean dry air generator capable of supplying the air with the atmospheric dew point of -70°C. It supplies the air compliant with the air cleanliness class, ISO8573-1:2010 (JIS B 8392-1:2012 [0:2:0]). re in () are enecification of the W type

MODEL		MAIRS-0.3	MAII	RS-NCP(W)				
Generating volume*3		10NL/min	10(10(16)NL/min				
Pressure	Reference: 0.2MPa (variable between 0.05MPa and 0.3MP							
Compressed air cleanliness class		JIS B 8392-1:2012 (IS08573-1:2010)						
Item	Class Description							
		Maximum number of particles per 1 m³ in response to the particle diameter d (µm).						
Maniana andida andad	0	0.1 < d ≤ 0.5	$0.5 < d \le 1.0$	1.0 < d ≤ 5.0				
Maximum particle content	0	10 pcs.	4 pcs.	2 pcs.				
		Provided with 0.01µm filter element.						
Pressure dew point (0.2 MPa)	2	2 -60°C or less (atmospheric dew point: -70°C o						
Total oil concentration	0	Liquid oil, oil mist, oil vapor <0.005mg/m³>						
Power consumption	0.06 to 0.3kW 0.1(0.035)kW							

Tank Units Standard Specifications

Tank unit SUS

The tank unit is a gas folder for the Mini-CUBE series. Capable of automatically starting / stopping the Mini-CUBE series depending on the storage pressure, it not only has an energy conservation effect, but also is an effective option for intermittently using a gas.

Since it has the same size as various Mini-CUBE generators, it can be placed on top of them. It is not necessary to secure additional tank installation space.

MODEL	T-10-SUS				
Volume	12.8L				
Pressure gauge	0 to 1.0MPa				
Pressure switch setting range	0.1 to 0.8MPa				
Tank material	SUS304				

- *1. Actual measured value at 1m in front of the device and at the height of 1m in an anechoic room.
- *2. Value of N₂ + Ar
- *3. Value converted into the 0°C atmospheric pressure in an environment where the ambient temperature is 20°C and the humidity is 60%RH. Generating volume and a dew point are lowered as the temperature and humidity rise.

To seek the accuracy, optional separate oxygen densitometer is required.

To seek the accuracy, optional separate oxygen densitometer is requ

Multifunction Intelligent Gas Mixer

BRENDA® SERIES



Applicable fluids Gas Air, N₂, O₂, He, Ar, CO₂, H₂, etc.

Max. flow rate Gas 10SCCM to 50SLM for 1 line, 100SLM in total

Accuracy Within ±1%F.S.

BRENDA series can produce a mixed gas at accurate gas mixture rate by a high-performance digital mass flow controller. Also, use of an 8-inch touch panel has simplified the concentration and flow rate settings of the gas mixing.

With fulfilled functions, the BRENDA series is provided with a VNC server function, allowing remote control through a network and at a mobile device via wireless access point.

- High-performance digital mass flow controller equipped.
- Ratio setting mode
 - Automatically controlled gas flow rate of each line by only setting a gas mixing ratio and a mixed gas flow rate. Ratio setting is down to the first decimal place (unit: %).
- Step mode

Allows programmed operation based on preset conditions. Possible to preset up to 9 steps of gas flow rate and time.

■ VNC server function

Allows remote control through a network and mobile device via wireless access point.

Data logging

Capable of setting a sampling cycle to log the operational status. Recorded data are retrievable from the USB port on the back of the device.

■ Various additional functions


Safety function: An emergency shutoff valve is installed at the mixed gas outlet, allowing shutoff by a manual switch and automatic shutoff against an alarm setting value.

Setting authority: Capable of setting a password for each setting item.

Upper- and lower-limit setting: Capable of setting the upper and lower limits of the flow rate and pressure of each line.

Flow rate integrating function: Capable of displaying integrated flow amount of each line. Convenient for monitoring the remaining capacity of the cylinder.

Dimensions



Standard Specifications

Туре	2-line	3-line	4-line							
MODEL	BR-2C	BR-3C	BR-4C							
Control system		Thermal mass flow controller control*1								
MFC accuracy	Within ±1%F.S.									
MFC response		Within 1sec								
Applicable gas	Air, N2, O2, He, Ar, CO2, H2	Air, N ₂ , O ₂ , He, Ar, CO ₂ , H ₂ * Capable of dealing with other corrosive gases and combustion gases* ² .								
Max. flow rate (N ₂ equivalent)	10SCCM to 50SLM for 1 line (10SCCM to 30SLM for CO ₂ , mixed gas flow rate up to 100SLM)									
Proof pressure	800kPa(G)									
Connection	Gas IN: Rc1/4 Gas OUT: Rc1/4									
Major gas contact part	SUS316, SUS	316L, Magnetic stainless steel, Ni, PTFE, PCTFE,	FKM, SUS304							
Ambient temperature / humidity	5 to 5	0°C (Accuracy assurance: 15°C to 35°C) / 10 to 8	0%RH							
Device dimensions	W380×D390×H330mm	W480×D39	0×H330mm							
Weight	30kg	40kg								
Power consumption		0.1kW								
Supply voltage	AC100 to 240V 1ø 50/60Hz									

- *1. A gas mixing ratio is based on the mixing method by volumetric flow ratio. *2. For the details of the gas type, flow rate and pressure range, feel free to inquire us.
- * For overseas specifications and options not specified above, feel free to inquire us.
- * The specifications are subject to change without prior notice due to product improvement.

Selection method

	MODEL														
Gas line	Model	1st line		2nd line		3rd line		4th line		Outlet	Calibration				
	Wodel	Gas name	Max. flow rate	Supply pressure	Gas name	Max. flow rate	Supply pressure	Gas name	Max. flow rate	Supply pressure	Gas name	Max. flow rate	Supply pressure	pressure	temperature
4 lines	BR-4C	Gas name (1)	Flow rate (1)	Supply pressure (1)	Gas name (2)	Flow rate (2)	Supply pressure (2)	Gas name (3)	Flow rate (3)	Supply pressure (3)	Gas name (4)	Flow rate (4)	Supply pressure (4)	Outlet	Calibration
3 lines	BR-3C	Gas name (1)	Flow rate (1)	Supply pressure (1)	Gas name (2)	Flow rate (2)	Supply pressure (2)	Gas name (3)	Flow rate (3)	Supply pressure (3)	-	-	-		temperature
2 lines	BR-2C	Gas name (1)	Flow rate (1)	Supply pressure (1)	Gas name (2)	Flow rate (2)	Supply pressure (2)	7-1	-	-	-	_	-	pressure	temperature
Example	BR-4C	N ₂	10SLM	0.2MPa(G)	02	10SLM	0.2MPa(G)	H ₂	5SLM	0.2MPa(G)	Ar	10SLM	0.2MPa(G)	0.1MPa(G)	20°C

Flow Meter Type Gas Mixer

GM SERIES



Applicable fluids Gas Air, N₂, O₂, He, H₂, Ar, CO₂, etc.

Max. flow rate Gas 10mL/min to 20L/min for 1 line, 40L/min in total

Accuracy ±2% F.S.

GM series is gas mixer consisting of **KOFLOC**'s mechanical precision flow control valve and flow meter. The device has incorporated constant flow rate unit capable of precision gas flow rate control from minute flow rate range.

Flow rate setting is easy and reliable without mutual interference, allowing constant supply of a stable mixed gas, even if there are fluctuations in the load pressure connected to the device. Having excellent stability and repeatability, GM series is highly evaluated in extensive fields.


- Superior stability and repeatability
- Excellent air-tightness
- Excellent temperature characteristic
- Cleanliness
- Available as a constant flow rate unit
- Capable of minute gas flow rate control
- Available for mixing 4 or more types of gases by optional specifications



GM-2B

Dimensions

≪GM-2B≫





Standard Specifications

MODEL	GM-2B GM-3B GM-4B							
Mixing method		Flow ratio mixing system						
Max. flow rate (Air atm condition)	10mL/min to 20L/min * Each line							
Applicable gas	Air, N ₂ O ₂ , He, H ₂ , Ar, CO ₂ * Other gases are also available.							
Accuracy		±2%F.S. * Each line						
	BS specification: BS, NBR, POM							
Major gas contact part	SUS specification: SUS316, FKM, PCTFE, PTFE							
Working temperature range		5 to 40°C						
Working pressure range		49 to 588kPa(G)						
Proof pressure		784kPa(G)						
Connection	Rc1/4 * IN, OUT							
Dimensions	ions W290×D350×H440mm W360×D350×H440mm W430×D350×H440mm							

Selection method

Gas line	MODEL										
	Model	Model Material	1st line		2nd line		3rd line		4th line		Working
	Model		Gas name	Max. flow rate	Gas name	Max. flow rate	Gas name	Max. flow rate	Gas name	Max. flow rate	pressure
4 lines	GM-4B	B(Brass) or SS(SUS)	Gas name (1)	Flow rate (1)	Gas name (2)	Flow rate (2)	Gas name (3)	Flow rate (3)	Gas name (4)	Flow rate (4)	Working pressure
3 lines	GM-3B	B(Brass) or SS(SUS)	Gas name (1)	Flow rate (1)	Gas name (2)	Flow rate (2)	Gas name (3)	Flow rate (3)	-	-	Working pressure
2 lines	GM-2B	B(Brass) or SS(SUS)	Gas name (1)	Flow rate (1)	Gas name (2)	Flow rate (2)	-	-	-	-	Working pressure
Example	GM-4B	В	N ₂	20L/min	02	10L/min	He	5L/min	Ar	5L/min	0.1MPa

- * The working pressure is pressure value to be set with the reducing valve in the device
- * The supply pressure of each gas to the device should be [operating pressure + 0.05MPa] at least.
- * If load pressure is applied to the device outlet, [operating pressure device outlet pressure] should be at least 0.05MPa.
- * If you have any request other than the above specifications, consult our sales office.

Custom-made design

Many of KOFLOC's products are produced to client's order according to their desired conditions specified in terms of our product type.

We will respond to your custom order about the product and specifications other than the standard specifications in the catalog.

We will consider in view of the price and quantity, ranging from the mass flow controllers/mass flow meters, flow meters and valves to the devices composed of their combinations. Consult our sales office.



General Catalog of Fluid Measurement Control Devices Issued on Mar. 31, 2023

Published by: KOFLOC Corp. Published by: Kenichi Fukunaga Edited by: Takahiro Minami Printed by: SHASHIN KAGAKU

We will replace the catalog if it has a manufacturing defect.

